

CONTENTS

ENGINE

Cylinder Head · Cylinder	B2
Crankshaft · Piston	B3 ~ B4
C.D.I. Magneto	B5
Water Pump	B6
Radiator · Hose	B7
Oil Pump	B8 ~ B9
Intake	B10 ~ B11
Carburetor	B12 ~ B13
Exhaust	B14
Crankcase	B15
Crankcase Cover	C2
Kick Starter	C3
Clutch	C4
Transmission	C5 ~ C6
Shift Cam · Fork	C7
Shift Shaft · Pedal	C8


Rear Wheel	D10 ~ D11
Handlebar · Cable	D12 ~ D13
Stand · Footrest	D14 ~ D15
Cowling	E2
Flasher Light	E3
Meter	E4
Headlight	E5
Taillight	E6
Electrical 1	E7
Electrical 2	E8
Handle Switch · Lever	E9

INDEX

Numerical Index	M1 ~ M3
Parts Name Index	M10 ~ M16

CHASSIS

Frame · Tool	C9
Front Fender · Rear Fender	C10
Side Cover	C11
Oil Tank	C12
Rear Arm	C13 ~ C14
Rear Suspension	C15
Steering	D2
Front Fork	D3 ~ D5
Fuel Tank	D6
Seat	D7
Front Wheel	D8 ~ D9



YAMAHA

PARTS CATALOGUE

DT125'82 (10V)

W.GERMANY

A2



A3

FOREWORD

This Parts Catalogue is related to the parts in use for the Yamaha DT 125 '82 (10V).

When you are ordering replacement parts for the DT 125 '82 (10V), refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after issue of the Parts Catalogue will be announced in the Yamaha Parts News.

It is advisable that according to the Yamaha Parts News you make necessary corrections to the Parts Catalogue on hand to keep it up-to-date.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

- U.R. Use size (thickness) and/or number as required
- U.N. Use as many as you need.
- A.P. Alternate Parts
- L.M. Local Made
- F# Frame No. (Applicable machine No.)

3. The parts marked with (*) in the parts number column of this Catalogue are not supplied with by Yamaha, those have to be found locally.

4. Parts, which are to be supplied in the form of assemblies, are listed with an indentation of one letter's space, and a dot (.) is put against the name of each part.

EXAMPLE CARBURETOR ASS'Y
 . JET, pilot
 . NOZZLE, main

5. Indication of No. of constituent parts for assembly



The numeral appearing on the right of each constituent part under the description indicates the quantity of such parts for each individual assembly unit.

EXAMPLE

Part No.	Description	Q'ty	Remarks
2F5-83310-60	FRONT FLASHER LIGHT ASS'Y	2	
115-83311-60	. BULB (6V-18W)	1	
1M1-83309-60	. REFLECTOR	1	

6. Initial Serial No. and Color Code

(A) Frame Serial No.	10V-000101 and following
(B) Engine Serial No.	10V-000101 and following



Color Code	Color Name	Abbreviate
G8	Sky Blue	SYB
33	Yamaha Black	YB
36	Clean White	W

7. Applicable colors of graphics are represented in the "Remarks" column by the letter(s) appropriately picked out of the full word(s) showing such colors.

EXAMPLE

Part No.	Description	Q'ty	Remarks
2N4-24110-00-X5	FUEL TANK COMP.	1	MAXIM RED
3J1-24240-10	. GRAPHIC, fuel tank set	1	for MXR

CONTENTS

ENGINE

Cylinder Head · Cylinder	B2
Crankshaft · Piston	B3 ~ B4
C.D.I. Magneto	B5
Water Pump	B6
Radiator · Hose	B7
Oil Pump	B8 ~ B9
Intake	B10 ~ B11
Carburetor	B12 ~ B13
Exhaust	B14
Crankcase	B15
Crankcase Cover	C2
Kick Starter	C3
Clutch	C4
Transmission	C5 ~ C6
Shift Cam · Fork	C7
Shift Shaft · Pedal	C8

CHASSIS

Frame · Tool	C9
Front Fender · Rear Fender	C10
Side Cover	C11
Oil Tank	C12
Rear Arm	C13 ~ C14
Rear Suspension	C15
Steering	D2
Front Fork	D3 ~ D5
Fuel Tank	D6
Seat	D7
Front Wheel	D8 ~ D9

Rear Wheel	D10 ~ D11
Handlebar · Cable	D12 ~ D13
Stand · Footrest	D14 ~ D15
Cowling	E2
Flasher Light	E3
Meter	E4
Headlight	E5
Taillight	E6
Electrical 1	E7
Electrical 2	E8
Handle Switch · Lever	E9

INDEX

Numerical Index	M1 ~ M3
Parts Name Index	M10 ~ M16

CONTENTS

ENGINE

Cylinder Head · Cylinder	B2
Crankshaft · Piston	B3 ~ B4
C.D.I. Magneto	B5
Water Pump	B6
Radiator · Hose	B7
Oil Pump	B8 ~ B9
Intake	B10 ~ B11
Carburetor	B12 ~ B13
Exhaust	B14
Crankcase	B15
Crankcase Cover	C2
Kick Starter	C3
Clutch	C4
Transmission	C5 ~ C6
Shift Cam · Fork	C7
Shift Shaft · Pedal	C8

CHASSIS

Frame · Tool	C9
Front Fender · Rear Fender	C10
Side Cover	C11
Oil Tank	C12
Rear Arm	C13 ~ C14
Rear Suspension	C15
Steering	D2
Front Fork	D3 ~ D5
Fuel Tank	D6
Seat	D7
Front Wheel	D8 ~ D9

Rear Wheel	D10 ~ D11
Handlebar · Cable	D12 ~ D13
Stand · Footrest	D14 ~ D15
Cowling	E2
Flasher Light	E3
Meter	E4
Headlight	E5
Taillight	E6
Electrical 1	E7
Electrical 2	E8
Handle Switch · Lever	E9

INDEX

Numerical Index	M1 ~ M3
Parts Name Index	M10 ~ M16

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-11111-00	HEAD, cylinder 1	1	
2	90116-08391	BOLT, stud	4	
3	95301-08800	NUT, crown	4	
4	90201-08649	WASHER, Plate	4	
5	94701-00204	PLUG, sPark	1	
6	10V-11181-00	GASKET, cylinder head 1	1	
7	10V-11311-00	CYLINDER 1	1	
8	95826-06010	BOLT, flange	1	
9	90430-06166	GASKET	1	
10	10V-11351-00	GASKET, cylinder	1	
11	10V-1131E-00	HOLDER 1	1	
12	90116-08318	BOLT, stud	2	
13	90116-08388	BOLT, stud	2	
14	91810-03014	PIN, dowel	2	
15	90179-08299	NUT	4	






FIG. 2 CRANKSHAFT-PISTON



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-11400-00	CRANKSHAFT ASSY	1	
2	10V-11412-00	•CRANK 1	1	
3	10V-11422-00	•CRANK 2	1	
4	3R2-11651-01	•ROD, connecting	1	
5	3M5-11621-00	•PIN, crank 1	1	
6	90209-22071	•WASHER	2	
7	93310-422K3	•BEARING, cylindrical	1	
8	10V-11631-00-96	PISTON (STD)	1	
	10V-11635-00	PISTON (1ST O/S 0.25MM)	1	AP
	10V-11636-00	PISTON (2ND O/S 0.50MM)	1	AP
	10V-11637-00	PISTON (3RD O/S 0.75MM)	1	AP
	10V-11638-00	PISTON (4TH O/S 1.00MM)	1	AP
9	10V-11610-00	PISTON RING SET (STD)	1	
	10V-11610-10	PISTON RING SET (1ST O/S)	1	AP
	10V-11610-20	PISTON RING SET (2ND O/S)	1	AP
	10V-11610-30	PISTON RING SET (3RD O/S)	1	AP
	10V-11610-40	PISTON RING SET (4TH O/S)	1	AP
10	93310-216J2	BEARING, cylindrical	1	
11	137-11633-00	PIN, Piston	1	
12	93450-17044	CIRCLIP	2	
13	93306-20529	BEARING (B6205C4)	1	
14	93306-30406	BEARING (B6304C3)	1	
15	93102-25269	OIL SEAL	1	
16	93103-28130	OIL SEAL	1	
17	90387-207F3	COLLAR	1	
18	90280-03017	KEY, woodruff	1	
19	90282-05047	KEY, straight	1	
20	10V-11536-00	GEAR, drive	1	

FIG. 2 CRANKSHAFT-PISTON




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
21	10V-11454-00	WEIGHT 1	1	
22	93306-30201	BEARING (B6302)	1	
23	93306-30305	BEARING (B6303)	1	
24	90282-05013	KEY, straight	1	
25	10V-11531-01	GEAR, balance wt	1	
26	90215-15200	WASHER, lock	1	
27	90179-12181	NUT	1	

FWD
10V351-2020

B4

FIG. 3 C.D.I MAGNETO




REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	10V-85500-20	C.D.I. MAGNETO ASSY	1	
2	10V-85550-20	•ROTOR ASSY	1	
3	10V-P-561-20	•BASE, magneto	1	
4	10V-85512-20	•COIL, source	1	
5	10V-85513-20	•COIL, lighting 1	1	
6	10V-85514-20	•COIL, lighting 2	1	
7	10V-85515-20	•LEAD WIRE ASSY	1	
8	10V-81328-20	•CLAMP	1	
9	104-81328-20	•CLAMP	1	
10	98502-04035	•SCREW, Pan head	4	
11	92902-04100	•WASHER, spring	4	
12	92901-04600	•WASHER, Plate	4	
13	98501-04018	•SCREW, Pan head	2	
14	92902-04100	•WASHER, spring	2	
15	92901-04600	•WASHER, Plate	2	
16	98501-04008	•SCREW, Pan head	2	
17	92901-04100	•WASHER, spring	2	
18	92901-04600	•WASHER, Plate	2	
19	90170-12067	NUT	1	
20	90201-12593	WASHER, Plate	1	
21	92901-12100	WASHER, spring	1	



ICV351-2030

B5

FIG. 4 WATER PUMP




REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	10V-12450-00	IMPELLER SHAFT ASSY	1	
2	93103-10113	OIL SEAL	1	
3	93603-22028	PIN, dowel	1	
4	10V-12459-00	GEAR, impeller shaft	1	
5	90201-08512	WASHER, Plate	2	
6	93430-07012	CIRCLIP	1	
7	10V-12426-00	SHAFT	1	
8	10V-12436-00	GEAR, drive	1	
9	90201-08512	WASHER, Plate	2	
10	10V-12422-00	COVER, housing	1	
11	10V-12428-00	GASKET, housing cover 2	1	
12	92604-10011	PIN, dowel	2	
13	92501-06020	SCREW, Pan head	2	
14	92501-06025	SCREW, Pan head	1	
15	95821-06010	BOLT, flange	1	
16	90430-06166	GASKET	1	



10V351-2040

B6

FIG. 5 RADIATOR HOSE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-12446-00	JOINT	1	
2	10V-12469-00	JOINT 1	1	
3	93210-16275	O-RING	3	
4	98906-06020	SCREW, bind	3	
5	10V-12481-00	PIPE 1	1	
6	10V-12482-00	PIPE 2	1	
7	90467-21058	CLIP	2	
8	90467-23067	CLIP	2	
9	10V-12464-00	STAY, radiator	1	
10	95801-08012	BOLT, flange	2	
11	90480-01327	GROMMET	1	
12	10V-12467-01	COVER, radiator	1	UR clean white
	10V-12467-11	COVER, radiator	1	UR yamaha black
	10V-12467-21	COVER, radiator	1	UR sky blue
13	10V- 2460-00	RADIATOR ASSY	1	
14	4L0-12462-00	.CAP, radiator	1	
15	10V-12465-00	DAMPER, radiator	1	
16	90387-072E7	COLLAR	2	
17	90480-15064	GROMMET	2	
18	97306-06025	BOLT	2	
19	92906-06100	WASHER, spring	2	
20	90201-06570	WASHER, plate	2	
21	90480-10070	GROMMET	2	
22	90154-05013	SCREW, binding	1	



10V351-2050

B7




B8

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-13101-00	OIL PUMP ASSY	1	
2	90445-05217	.HOSE	1	
3	353-13552-01	.NOZZLE	1	
4	90468-02033	.CLIP	1	
5	93505-32002	.BALL	1	
6	278-13169-00	.SPRING, check ball	1	
7	90430-04004	.GASKET	1	
8	9890'-04008	.SCREW, blind	1	
9	137-13138-01	.PLATE, adjusting	1	
10	137-13137-00-03	.SHIM (0.3T)	1	UR
	137-13137-00-05	.SHIM (0.5T)	1	UR
	137-13137-00-10	.SHIM (1.0T)	1	UR
11	92901-05100	.WASHER, spring	1	
12	95301-05600	.NUT	1	
13	10V-13175-00	SHAFT, worm	1	
14	90201-08624	WASHER, Plate	1	
15	126-13116-00	GASKET, Pump case	1	
16	98501-05016	SCREW, Pan head	2	
17	93101-10001	OIL SEAL	1	
18	137-13176-00	METAL, worm shaft outer	1	
19	10V-13178-00	GEAR, Pump drive	1	
20	93603-22028	PIN, dowel	1	
21	93430-08036	CIRCLIP	2	
22	363-13133-01	CLIP	1	
23	93210-07100	O-RING	1	
24	90468-02033	CLIP	1	
25	90468-15020	CLIP	1	
26	10V-13416-00	PIPE, oil	1	


FIG. 6 OIL PUMP

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	10V-13174-00	HOLDER, oil Pipe	1	
28	90467-08000	CLIP	1	



10V351-2060

B9




10V351-2070

FIG. 7 INTAKE

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-13610-00	REED VALVE ASSY	1	
2	10V-13613-00	•REED, valve	2	
3	10V-13616-00	•STOPPER, reed valve	2	
4	97602-03108	•SCREW, Pan head with washer	4	
5	311-13621-01	GASKET, valve seat	1	
6	10V-13565-00	JOINT, carburetor	1	
7	90460-44108	CLAMP, hose	1	
8	97306-06025	BOLT	4	
9	92906-06600	WASHER, Plate	4	
10	90462-05005	CLAMP	1	
11	10V-13584-00	PIPE, manifold	1	
12	90467-20050	CLIP	1	
13	10V-13581-00	CHAMBER, air	1	
14	10V-13584-00	PIPE, manifold	1	
15	90467-21008	CLIP	1	
16	90467-20050	CLIP	1	
17	90119-06056	BOLT, with washer	1	
18	10V-14411-00	CASE, air cleaner 1	1	
19	10V-14452-00	SEAL	1	
20	10V-14421-00	CASE, air cleaner 2	1	
21	97701-40516	SCREW, Panhead tapping	13	
22	10V-14476-00	SEAL	1	
23	10V-14468-00	PLATE, element fitting	1	
24	10V-W4451-00	ELEMENT, SET	1	
25	10V-14412-00	CAP, cleaner case 1	1	
26	92501-06060	SCREW, Pan head	1	
27	92901-06600	WASHER, Plate	1	
28	10V-14437-00	DUCT	1	

FIG. 7 INTAKE


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	10V-14453-00	JOINT, air cleaner	1	
30	10V-14477-00	PLATE	1	
31	90460-49058	CLAMP, hose	1	



10V351-2070

B11


FIG. 8 CARBURETOR



10V351-2080

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-14101-00	CARBURETOR ASSY 1	1	
2	260-14142-20	•JET, Pilot (#20.0)	1	
3	137-14143-15	•JET, main (#075)	1	UR
	137-14143-16	•JET, main (#080)	1	UR
	137-14143-17	•JET, main (#085)	1	UR
4	168-14190-25	•NEEDLE VALVE ASSY	1	
5	117-14186-00	•PIN, float	1	
6	214-14195-00	•WASHER, needle valve	1	
7	314-14185-10	•FLOAT	1	
8	166-14116-13	•NEEDLE	1	
9	2F5-14141-42	•NOZZLE, main	1	
10	214-14147-00	•O-RING	2	
11	2N4-14145-00	•HOLDER	1	
12	500-14115-00	•PLUG, screw	1	
13	558-14147-00	•O-RING	1	
14	4E9-14184-00	•GASKET, float chamber	1	
15	493-14103-00	•SPRING, throttle stop	1	
16	443-14122-00	•SCREW, throttle	1	
17	127-14161-00	•BOLT, cable adjusting	1	
18	98501-04016	•SCREW, Pan head	4	
19	92902-04100	•WASHER, spring	4	
20	3X3-14197-00	•PIPE	1	
21	4U5-14171-00	•PLUNGER, starter	1	
22	2Y1-14112-20	•VALVE, throttle 1	1	
23	97602-03100	•SCREW, Pan head with washer	2	
24	164-14137-00	•CLIP	1	
25	3X3-14163-00	•CAP	1	
26	1T9-14155-00	•GUIDE, cable	1	

FIG. 8 CARBURETOR



ICV351-2080

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	509-14198-00	.GASKET	1	
28	509-14274-00	.CONNECTOR	1	
29	2Y1-14136-00	.SEAT, sPring	1	
30	174-14134-00	.SPRING, air adjusting	1	
31	354-14147-00	.O-RING	1	
32	525-14123-00	.SCREW, air adjusting	1	
33	10V-14158-00	.TOP, mixing chamber	1	
34	361-14147-00	.O-RING	1	
35	363-14137-00	.CLIP	1	
36	248-14131-00	.SPRING, throttle valve	1	
37	183-14197-01	.PIPE	1	

B13





FIG. 9 EXHAUST

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-14610-01	EXHAUST PIPE ASSY 1	1	
2	152-14613-00	GASKET, exhaust Pipe	1	
3	90116-08042	BOLT, stud	2	
4	90179-08210	NUT	2	
5	90480-01326	GROMMET	1	
6	90387-077F4	COLLAR	1	
7	565-14771-00	STAY, muffler 1	1	
8	95806-06012	BOLT, flange	2	
9	97306-06025	BOLT	1	
10	10V-14753-00	SILENCER, exhaust	1	
11	1W2-14714-00	GASKET, muffler	1	
12	90460-37026	CLAMP, hose	2	
13	95806-08012	BOLT, flange	2	
14	10V-14718-01	PROTECTOR, muffler 1	1	
15	98906-06010	SCREW, bind	3	
16	90202-06010	WASHER, Plate	6	
17	10V-14758-00	PROTECTOR, silencer	1	
18	98906-06010	SCREW, bind	2	
19	90202-06010	WASHER, Plate	4	
20	10V-14747-00	DAMPER, muffler	1	

10V351-2090

FIG. 10 CRANKCASE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-15111-00	CRANKCASE 1	1	
2	10V-15121-00	CRANKCASE 2	1	
3	91830-22016	PIN, dowel	2	
4	92501-06045	SCREW, Pan head	9	
5	90340-12059	PLUG, straight screw	1	
6	90430-12038	GASKET	1	
7	10V-15128-00	HOLDER	1	
8	92501-08010	SCREW, Pan head	1	
9	92501-06030	SCREW, Pan head	1	
10	92501-06075	SCREW, Pan head	2	
11	92901-06600	WASHER, Plate	2	
12	90462-12105	CLAMP	1	
13	90480-01209	GROMMET	1	
14	353-13115-01	CONNECTOR, suction Pipe	1	
15	90445-09082	HOSE	1	
16	90701-122F8	WASHER, Plate	2	
17	90338-05038	PLUG	1	
18	90338-16015	PLUG	1	

CONTENTS

ENGINE

Cylinder Head - Cylinder	B2
Crankshaft - Piston	B3 ~ B4
C.D.I. Magneto	B5
Water Pump	B6
Radiator - Hose	B7
Oil Pump	B8 ~ B9
Intake	B10 ~ F11
Carburetor	B12 ~ B13
Exhaust	B14
Crankcase	B15
Crankcase Cover	C2
Kick Starter	C3
Clutch	C4
Transmission	C5 ~ C6
Shift Cam - Fork	C7
Shift Shaft - Pedal	C8

Rear Wheel	D10 ~ D11
Handlebar - Cable	D12 ~ D13
Stand - Footrest	D14 ~ D15
Cowling	E2
Flasher Light	E3
Meter	E4
Headlight	E5
Tail Light	E6
Electrical 1	E7
Electrical 2	E8
Handle Switch - Lever	E9

INDEX

Numerical Index	M1 ~ M3
Parts Name Index	M10 ~ M16

CHASSIS

Frame - Tool	C9
Front Fender - Rear Fender	C10
Side Cover	C11
Oil Tank	C12
Rear Arm	C13 ~ C14
Rear Suspension	C15
Steering	D2
Front Fork	D3 ~ D5
Fuel Tank	D6
Seat	D7
Front Wheel	D8 ~ D9

CONTENTS

ENGINE

Cylinder Head · Cylinder	B2
Crankshaft · Piston	B3 ~ B4
C.D.I. Magneto	B5
Water Pump	B6
Radiator · Hose	B7
Oil Pump	B8 ~ B9
Intake	B10 ~ B11
Carburetor	B12 ~ B13
Exhaust	B14
Crankcase	B15
Crankcase Cover	C2
Kick Starter	C3
Clutch	C4
Transmission	C5 ~ C6
Shift Cam · Fork	C7
Shift Shaft · Pedal	C8

CHASSIS


Frame · Tool	C9
Front Fender · Rear Fender	C10
Side Cover	C11
Oil Tank	C12
Rear Arm	C13 ~ C14
Rear Suspension	C15
Steering	D2
Front Fork	D3 ~ D5
Fuel Tank	D6
Seat	D7
Front Wheel	D8 ~ D9

Rear Wheel	D10 ~ D11
Handlebar · Cable	D12 ~ D13
Stand · Footrest	D14 ~ D15
Cowling	E2
Flasher Light	E3
Meter	E4
Headlight	E5
Taillight	E6
Electrical 1	E7
Electrical 2	E8
Handle Switch · Lever	E9


INDEX

Numerical Index	M1 ~ M3
Parts Name Index	M10 ~ M16

FIG. 11 CRANKCASE COVER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-15411-00	COVER, crankcase 1	1	
2	10V-15455-00	GASKET 1	1	
3	92506-06030	SCREW, Pan head	5	
4	10V-15421-00	COVER, crankcase 2	1	
5	91810-02014	PIN, dowel	2	
6	10V-15451-00	GASKET, crankcase cover	1	
7	92506-06030	SCREW, Pan head	7	
8	92506-06035	SCREW, Pan head	1	
9	10V-15416-00	COVER, oil Pump	1	
10	10V-15456-00	GASKET, oil Pump cover 1	1	
11	92506-06030	SCREW, Pan head	4	
12	3Y1-15363-00	PLUG, oil	1	
13	93210-19123	O-RING	1	
14	3Y1-15361-00	GAUGE, level	1	
15	90465-14202	CLAMP	1	



10V351-2110


C2

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-15660-00	KICK AXLE ASSY	1	
2	10V-15641-00	GEAR, kick	1	
3	90468-26048	CLIP	1	
4	90201-202F9	WASHER, Plate	1	
5	90508-26556	SPRING, torsion	1	
6	10V-15666-00	SPACER	1	
7	10V-15651-00	GEAR, kick idle	1	
8	90201-154E8	WASHER, Plate	2	
9	93440-15012	CIRCLIP	2	
10	10V-15620-00	KICK CRANK ASSY	1	
11	10V-15621-00	•BOSS, kick crank	1	
12	90501-12081	•SPRING, compression	1	
13	93507-32009	•BALL	1	
14	90201-127E0	•WASHER, Plate	1	
15	93430-08042	•CIRCLIP	1	
16	156-15618-01	•COVER, kick lever	1	
17	90179-12374	NUT	1	
18	93109-20014	OIL SEAL	1	



C₃

FIG. 13 CLUTCH




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-16150-00	PRIMARY DRIVEN GEAR COMP.	1	
2	4Y2-16371-00	BOSS, clutch	1	
3	1V1-16324-00	PLATE, clutch 1	5	
4	10V-16321-00	PLATE, friction	6	
5	4V0-161E4-00	PLATE, thrust 1	1	
6	10V-16351-00	PLATE, Pressure 1	1	
7	90E01-20122	SPRING, compression	4	
8	90119-05C01	BOLT, with washer	4	
9	2A6-16111-00	GEAR, Primary drive (22T)	1	
10	90204-12007	WASHER, spring	1	
11	90179-12244	NUT	1	
12	90208-17032	WASHER, conical spring	1	
13	10V-16154-00	PLATE, thrust 1	1	
14	93604-07141	PIN, dowel	1	
15	90215-12007	WASHER, lock	1	
16	90171-12060	NUT	1	
17	1W1-16358-00	PLATE, Push	1	
18	1W1-16356-01	ROD, Push 1	1	
19	92901-06200	WASHER, Plain	1	
20	95301-06600	NUT	1	
21	93503-16010	BALL	1	
22	4V0-16357-00	ROD, Push 2	1	
23	10V-16380-00	PUSH LEVER ASSY	1	
24	90508-20555	SPRING, torsion	1	
25	90201-14217	WASHER, Plate	1	
26	93104-14004	OIL SEAL	1	

10V351-2130

C4

FIG. 14 TRANSMISSION



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-17411-00	AXLE, main	1	
2	5V7-17151-00	GEAR, 5th Pinion (23T)	1	
3	5V7-17131-00	GEAR, 3rd/4th Pinion (21T)	1	
4	10V-17161-00	GEAR, 6th Pinion	1	
5	2A6-17121-00	GEAR, 2nd Pinion (14T)	1	
6	90201-20266	WASHER, Plate	2	
7	93410-20038	CIRCLIP	3	
8	93306-30303	BEARING (B6303Z)	1	
9	93311-41530	BEARING, cylindrical	1	
10	10V-17421-00	AXLE, drive	1	
11	5V7-17211-00	GEAR, 1st wheel (35T)	1	
12	10V-17251-00	GEAR, 5th wheel	1	
13	5V7-17231-00	GEAR, 3rd wheel (28T)	1	
14	5V7-17211-00	GEAR, 4th wheel (25T)	1	
15	10V-17261-00	GEAR, 6th wheel	1	
16	5V7-17221-00	GEAR, 2nd wheel (31T)	1	
17	164-17427-00-10	SHIM 1 (1.0T)	1	
18	93440-15012	CIRCLIP	1	
19	90209-18135	WASHER	2	
20	93410-22039	CIRCLIP	4	
21	90201-22555	WASHER, Plate	1	
22	93311-31515	BEARING, cylindrical	1	
23	93306-20418	BEARING (B6204CS)	1	
24	93102-20143	OIL SEAL	1	
25	5H0-17461-50	SPROCKET, drive (15T)	1	
26	5H0-17456-00	HOLDER, sprocket	1	
27	7321-06010	BOLT	2	
28	10V-17471-00	PLATE, cover	1	




10V351-2140

C5

FIG. 14 TRANSMISSION


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	92501-06012	SCREW Fan head	2	



10V351-2140

C6

FIG. 15 SHIFT CAM•FORK



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-18540-00	SHIFT CAM ASSY	1	
2	5R2-18185-00	•SEGMENT	1	
3	93306-00418	•BEARING	1	
4	90282-04036	•KEY, straight	1	
5	3R4-18561-00	•PLATE, side 1	1	
6	98701-05016	•SCREW, flat head	1	
7	126-18542-00	•POINT, neutral	1	
8	90201-203F0	•WASHER, plate	1	
9	10V-18140-00	STOPPER LEVER ASSY	1	
10	90508-26E54	SPRING, torsion	1	
11	1W1-18177-00	BOLT, stopper	1	
12	93430-10C16	CIRCLIP	1	
13	10V-18511-00	FORK, shift 1	1	
14	3R3-13512-00	FORK, shift 2	1	
15	10V-18513-00	FORK, shift 3	1	
16	90250-06013	PIN, straight	3	
17	3R4-18531-00	BAR, shift fork guide 1	1	
18	10V-18535-00	BAR, shift fork guide 2	1	




10V351-2.50

C7

FIG. 16 SHIFT SHAFT•PEDAL


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-18101-00	SHIFT SHAFT ASSY	1	
2	93430-08036	CIRCLIP	1	
3	10V-18110-00	SHIFT PEDAL ASSY	1	
4	1W6-18113-00	COVER, shift Pedal	1	
5	97321-06020	BOLT	1	
6	93101-12060	OIL SEAL	1	
7	90508-32553	SPRING, torsion	1	



10V351-2160

C8


FIG. 17 FRAME• TOOL



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-21110-40-33	FRAME COMP	1	yamaha black
2	90105-08222	BOLT, washer based	1	
3	90105-08221	BOLT, washer based	1	
4	92901-08200	WASHER, Plain	1	
5	90185-08089	NUT, self-locking	1	
6	10V-21471-00	PROTECTOR, engine	1	
7	90480-14023	GROMMET	3	
8	90387-07391	COLLAR	3	
9	97301-06025	BOLT	3	
10	431-24181-00	DAMPER, locating 1	2	
11	10V-21485-00	DAMPER, rubber 1	2	
12	2K7-2148A-00	SHAFT	1	
13	10V-22178-00	TENSIONER	1	
14	10V-22184-00	BUSH	1	
15	90201-08113	WASHER, Plate	1	
16	95806-08050	BOLT, flange	1	
17	9560F-08100	NUT, u	1	
18	5A8-21308-00	HELMET HANGER ASSY	1	
19	92706-06020	SCREW, flat head	1	
20	10V-28100-10	TOOL KIT	1	
21	10V-2811G-00	BAND	1	
22	10V-28135-00	SPANNER, sPecial	1	

10V332-2170

FIG. 18 FRONT FENDER, REAR FENDER




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-21511-00	FENDER, front	1	UR clean white
	10V-21511-10	FENDER, front	1	UR yamaha black
	10V-21511-20	FENDER, front	1	UR sky blue
2	90119-06063	BOLT, with washer	4	
3	90209-06187	WASHER	4	
4	10V-21611-00	FENDER, rear	1	UR clean white
	10V-21611-10	FENDER, rear	1	UR yamaha black
	10V-21611-20	FENDER, rear	1	UR sky blue
5	90119-06063	BOLT, with washer	4	
6	90119-06061	BOLT, with washer	2	
7	90201-06557	WASHER, Plate	2	
8	95601-06100	NUT, u	2	
9	10V-21691-00	FLAP	1	
10	10V-21685-10	BRACKET, license	1	
11	10V-21621-00	FLAP	1	
12	90267-40029	RIVET, blind	4	
13	90201-044A2	WASHER, Plate	8	



10V332-2180

C10

FIG. 19 SIDE COVER




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-21711-00	COVER, side 1	1	UR clear white
	10V-21711-10	COVER, side 1	1	UR yamaha black
	10V-21711-20	COVER, side 1	1	UR sky blue
2	90146-06012	SCREW, oval fillister	1	
3	90201-062A8	WASHER, Plate	1	
4	4U5-2176E-00	PLATE	1	
5	90480-01141	GROMMET	1	
6	431-24181-00	DAMPER, locating 1	1	
7	10V-24181-00	DAMPER, locatin. 1	1	
8	10V-21721-00	COVER, side 2	1	UR clear white
	10V-21721-10	COVER, side 2	1	UR yamaha black
	10V-21721-20	COVER, side 2	1	UR sky blue
9	90146-06012	SCREW, oval fillister	1	
10	90201-062A8	WASHER, Plate	1	
11	4U5-2176E-00	PLATE	1	
12	90480-01141	GROMMET	1	
13	90480-12325	GROMMET	1	
14	10V-21717-00	DAMPER, side cover	1	
15	10V-2177A-00	BOX	1	
16	90480-18324	GROMMET	1	
17	10V-21781-10	EMBLEM 1	2	UR for w
	10V-21781-01	EMBLEM 1	2	UR for yb, syb
18	95801-06016	BOLT, flange	3	
19	90119-06043	BOLT, with washer	1	



10V351-2190

C11


FIG. 20 OIL TANK



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-21751-00	TANK, oil	1	
2	10V-21771-00	BODY, cap	1	
3	10V-21875-00	CAP	1	
4	10V-21745-00	PIPE, oil tank breather	1	
5	10V-21876-00	PIPE, breather	1	
6	90467-08003	CLIP	2	
7	90467-08003	CLIP	1	
8	90480-14023	GROMMET	2	
9	30387-07391	COLLAR	2	
10	97301-06022	BOLT	2	
11	10V-21877-00	PIPE, over flow	1	
12	90467-10008	CLIP	2	

FWD
10V351-2200

C12




10V351-2210

FIG. 21 REAR ARM

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-22110-00-35	REAR ARM COMP.	1	silver
2	90386-18028	BUSH	2	
3	90337-127F2	COLLAR	2	
4	401-22127-00	SHIM	1	
5	401-22128-01	SEAL, guard	2	
6	93109-18020	OIL SEAL	2	
7	434-22141-00	SHAFT, Pivot	1	
8	90195-12046	NUT, self-locking	1	
9	92901-12100	WASHER, spring	1	
10	10V-22151-00	SEAL, guard	1	
11	90119-05062	BOLT, with washer	1	
12	10V-22153-00	GUARD, chain	1	
13	95801-06050	BOLT, flange	2	
14	10V-22311-00	CASE, chain	1	
15	90119-05062	BOLT, with washer	3	
16	10V-22312-00	CASE, chain 2	1	
17	90119-05062	BOLT, with washer	2	
18	10V-22179-00	ARM, tensioner	1	
19	93104-11056	OIL SEAL	2	
20	2N0-22178-00	TENSIONER	1	
21	10V-22187-00	GUIDE, chain	1	
22	98501-05035	SCREW, Pan head	2	
23	95301-05700	NUT	2	
24	90508-35552	SPRING, torsion	1	
25	90109-08661	BOLT	1	
26	120-27430-02	REAR FOOTREST ASSY 1	2	
27	120-27432-02	•BRACKET 1	1	
28	120-27433-00	•COVER, rear footrest	1	

FIG. 21 REAR ARM




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90201-20279	•WASHER, Plate	1	
30	120-27431-00	•FOOTREST, rear 1	1	
31	90240-06009	•PIN, clevis	1	
32	91401-16015	•PIN, cotter	1	
33	95301-12700	NUT	2	
34	10V-22147-00	PROTECTOR, chain	1	
35	3J0-22131-00	STAY, chain case 1	1	
36	90387-05682	COLLAR	2	
37	90119-05067	BOLT, with washer	2	

10V351-2210

C14

FIG. 22 REAR SUSPENSION

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-22210-00	SHOCK ABSORBER ASSY, rear	1	
2	3R4-22226-00	•BUSH, shock absorber lower	1	
3	90380-12051	•BUSH, solid	2	
4	1W1-22216-00	•BUSH, rear shock absorber	1	
5	90109-10662	BOLT	1	
6	92901-10100	WASHER, spring	1	
7	95602-10100	NUT, u	1	
8	1W1-22128-00	COVER, thrust 1	2	
9	90210-12092	PIN, clevis	1	
10	92901-12600	WASHER, plate	1	
11	91401-30025	PIN, cotter	1	



10V-51-2220

C15

CONTENTS

ENGINE

Cylinder Head · Cylinder	B2
Crankshaft · Piston	B3 ~ B4
C.D.I. Magneto	B5
Water Pump	B6
Radiator · Hose	B7
Oil Pump	B8 ~ B9
Intake	B10 ~ B11
Carburetor	B12 ~ B13
Exhaust	B14
Crankcase	B15
Crankcase Cover	C2
Kick Starter	C3
Clutch	C4
Transmission	C5 ~ C6
Shift Cam · Fork	C7
Shift Shaft · Pedal	C8

CHASSIS

Frame · Tool	C9
Front Fender · Rear Fender	C10
Side Cover	C11
Oil Tank	C12
Rear Arm	C13 ~ C14
Rear Suspension	C15
Steering	D2
Front Fork	D3 ~ D5
Fuel Tank	D6
Seat	D7
Front Wheel	D8 ~ D9

Rear Wheel	D10 ~ D11
Handlebar · Cable	D12 ~ D13
Stand · Footrest	D14 ~ D15
Cowling	E2
Flasher Light	E3
Meter	E4
Headlight	E5
Taillight	E6
Electrical 1	E7
Electrical 2	E8
Handle Switch · Lever	E9

INDEX

Numerical Index	M1 ~ M3
Parts Name Index	M10 ~ M16

CONTENTS

ENGINE

Cylinder Head - Cylinder	B2
Crankshaft - Piston	B3 ~ B4
C.D.I. Magneto	B5
Water Pump	B6
Radiator - Hose	B7
Oil Pump	B8 ~ B9
Intake	B10 ~ B11
Carburetor	B12 ~ B13
Exhaust	B14
Crankcase	B15
Crankcase Cover	C2
Kick Starter	C3
Clutch	C4
Transmission	C5 ~ C6
Shift Cam - Fork	C7
Shift Shaft - Pedal	C8

CHASSIS


Frame - Tool	C9
Front Fender - Rear Fender	C10
Side Cover	C11
Oil Tank	C12
Rear Arm	C13 ~ C14
Rear Suspension	C15
Steering	D2
Front Fork	D3 ~ D5
Fuel Tank	D6
Seat	D7
Front Wheel	D8 ~ D9

Rear Wheel	D10 ~ D11
Handlebar - Cable	D12 ~ D13
Stand - Footrest	D14 ~ D15
Cowling	E2
Flasher Light	E3
Meter	E4
Headlight	E5
Taillight	E6
Electrical 1	E7
Electrical 2	E8
Handle Switch - Lever	E9

INDEX

Numerical Index	M1 ~ M3
Parts Name Index	M10 ~ M16

FIG. 23 STEERING




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	156-23411-00	RACE, ball 1	1	
2	164-23462-00	SEAL, steering	1	
3	156-23412-00	RACE, ball 2	1	
4	93501-04011	BALL	19	
5	122-23411-00	RACE, ball 1	1	
6	122-23412-00	RACE, ball 2	1	
7	93503-16010	BALL	22	
8	583-23416-01	COVER, ball race 2	1	
9	90179-25033	NUT	1	
10	10V-23435-00-98	CROWN, handle	1	low gloss black
11	90105-14102	BOLT, washer based	1	
12	90105-08219	BOLT, washer based	4	
13	1E6-23441-00-98	FOLDER, handle upper	2	low gloss black
14	95826-08035	BOLT, flange	4	
15	10V-23317-00	HOLDER, cable	1	
16	1W1-23389-00	GUIDE, cable	1	
17	10V-23318-00	HOLDER, cable 1	1	
18	95801-06010	BOLT, flange	1	
19	3Y1-23319-00	HOLDER, cable 2	1	
20	95806-06012	BOLT, flange	1	
21	*	STEERING LOCK ASSY	1	LM
22	10V-23389-00	GUIDE, cable	1	
23	95806-06010	BOLT, flange	1	

FWD
10V351-2230

D2

FIG. 24 FRONT FORK




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-23102-00	FRONT FORK ASSY (L.H)	1	
2	10V-23130-00	•FORK UNIT ASSY	1	
3	462-23392-02	••WASHER, sPecia	1	
4	2A6-23119-00	••PLUG, drain	1	
5	10V-23144-00	•SEAL, dust	1	
6	1J3-23156-00	•CLIP, oil seal	1	
7	10V-23145-00	•OIL SEAL	1	
8	10V-23147-00	•O-RING	1	
9	10V-23110-00	•INNER TUBE COMP.1	1	
10	10V-23351-00	•SPRING	1	
11	10V-23141-00	•SPRING, front fork	1	
12	10V-23171-00	•PISTON, front fork	1	
13	10V-23125-00	•METAL, slide 1	1	
14	2F3-23157-00	•PISTON RING, front fork	1	
15	10M-23151-00	•SPRING, rebound	1	
16	10V-23135-00	•METAL, slide 2	1	
17	10V-23166-00	•SPACER, oil lock	1	
18	3M7-23181-00	•BOLT, hexagon socket head	1	
19	1J3-23168-00	•CAP, front fork	1	
20	1J3-23183-01	•RING, stopper	1	
21	1T4-23111-00	•SEAT, sPring	1	
22	2F3-23114-00	•GASKET	1	
23	10V-23142-00	•SEAT, sPring upper	1	
24	10V-23192-00	•BAND	1	
25	10V-23191-00	•BOOT	1	
26	10V-23103-00	FRONT FORK ASSY (R.H)	1	
27	10V-23140-00	•FORK UNIT ASSY 2	1	
28	462-23392-02	••WASHER, sPecial	1	

10V351-2240

D3


FIG. 24 FRONT FORK



10V351-2240

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	2A6-23119-00	•PLUG, drain	1	
30	10V-23144-00	•SEAL, dust	1	
31	1J3-23156-00	•CLIP, oil seal	1	
32	10V-23145-00	•OIL SEAL	1	
33	10V-23147-00	•O-RING	1	
34	10V-23110-00	•INNER TUBE COMP.1	1	
35	10V-23351-00	•SPRING	1	
36	10V-23141-00	•SPRING, front fork	1	
37	10V-23171-00	•PISTON, front fork	1	
38	10V-23125-00	•METAL, slide 1	1	
39	2F3-23157-00	•PISTON RING, front fork	1	
40	10V-23151-00	•SPRING, rebound	1	
41	10V-23135-00	•METAL, slide 2	1	
42	10V-23166-00	•SPACER, oil lock	1	
43	3M7-23181-00	•BOLT, hexagon socket head	1	
44	1J3-23168-00	•CAP, front fork	1	
45	1J3-23163-01	•RING, stopper	1	
46	1T4-23111-00	•SEAT, spring	1	
47	2F3-23112-00	•GASKET	1	
48	10V-23142-00	•SEAT, spring upper	1	
49	10V-23192-00	•BAND	1	
50	10V-23191-00	•BOOT	1	
51	10V-23340-30-90	UNDER BRACKET COMP.	1	uni chrome (oil- ack)
52	10V-23346-00	BOLT 1	4	
53	10V-2331E-00	GUIDE, cable	1	
54	92506-06012	SCREW, Pan head	1	
55	92906-06100	WASHER, spring	1	
56	10V-23319-00	HOLDER, cable 2	1	

FIG. 24 FRONT FORK




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
57	1W1-23389-00	GUIDE, cable	1	

10V351-2240

D5


FIG. 25 FUEL TANK



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-24110-00-01	FUEL TANK COMP.	1	UR clean white
	10V-24110-00-02	FUEL TANK COMP.	1	UR yamaha black
	10V-24110-00-03	FUEL TANK COMP.	1	UR sky blue
2	10V-24240-00	•GRAPHIC SET	1	UR for w
	10V-24240-10	•GRAPHIC SET	1	UR for yb
	10V-24240-20	•GRAPHIC SET	1	UR for syb
3	4U5-24182-00	DAMPER, locating 2	2	
4	10V-24500-00	FUEL COCK ASSY 1	1	
5	4X8-24534-00	•SEAL, cock	1	
6	4X8-24565-00	•GASKET	1	
7	4X8-24512-00	•GASKET	1	
8	4X8-24535-00	•SCREW, lever fitting	1	
9	4X8-24515-01	•NET, filter 2	1	
10	90149-06011	SCREW	2	
11	90202-06010	WASHER, Plate	2	
12	90445-09097	HOSE	1	
13	90467-08003	CLIP	2	
14	3Y1-24610-01	CAP ASSY	1	
15	278-24181-00	DAMPER, locating 1	2	
16	10V-24182-00	DAMPER, locating 2	1	
17	10V-24183-00	DAMPER, locating 3	1	
18	97301-06012	BOLT	1	
19	92901-06100	WASHER, spring	1	
20	10V-24186-00	WASHER, special	1	

10V351-2250

FIG. 26 SEAT




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-W2472-20	DOUBLE SEAT ASSY	1	UR red
	10V-W2472-30	DOUBLE SEAT ASSY	1	UR black
2	10V-24731-20	•COVER, double seat	1	UR red
	10V-24731-30	•COVER, double seat	1	UR black
3	10V-24738-10	BRACKET, seat	1	
4	10V-24748-10	BRACKET, seat	1	
5	90101-08304	BOLT	6	
6	10V-24754-00	HOOK, seat	1	
7	10V-24774-00	PIN	1	
8	10V-24728-00	BRACKET, seat	1	
9	10V-24776-00	LEVER, seat	1	
10	93430-06005	CIRCLIP	1	
11	371-27114-00	STOPPER, main stand	2	
12	214-24724-00	DAMPER, seat	2	
13	509-24724-00	DAMPER, seat	1	
14	90183-05004	NUT, spring	2	
15	10V-24773-00	HANDLE, seat	1	
16	95806-08016	BOLT, flange	4	
17	92906-08200	WASHER, plain	4	



10V332-2260

D7

FIG. 27 FRONT WHEEL




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2A6-25111-00-9	HUB, front	1	low gloss black
2	93306-30102	BEARING (B6301)	2	
3	90560-12138	SPACER	1	
4	93102-18008	OIL SEAL	1	
5	109-25315-00	FLANGE, spacer	1	
6	4F2-25121-00-98	PLATE, brake shoe	1	low gloss black
7	93105-47007	OIL SEAL	1	
8	3Y6-2533A-01	PLATE, indicator	1	
9	437-25330-01	BRAKE SHOE COMP.	2	
10	90506-10036	SPRING, tension	2	
11	248-25135-11	GEAR, drive	1	
12	109-25136-00	BUSH	1	
13	248-25138-11	GEAR, meter	1	
14	93104-07003	OIL SEAL	1	
15	9C201-07076	WASHER, plate	1	
16	90201-20269	WASHER, plate	2	
17	183-25149-00	CLUTCH, meter	1	
18	93410-20009	CIRCLIP	1	
19	2N4-25155-00	LEVER, camshaft	1	
20	90101-06278	BOLT	1	
21	95601-06100	NUT, u	1	
22	248-25351-10	CAMSHAFT	1	
23	94416-21310	RIM (1.60-21)	1	
24	2A6-25104-00	SPOKE SET, front	1	
25	94127-21779	TIRE (2.75-21)	1	
26	94227-21123	TUBE (2.75-21)	1	
27	94330-21084	BAND, rim (3.00-21)	1	
28	90338-09130	PLUG	1	



10V332-2270

D8

FIG. 27 FRONT WHEEL




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90387-12265	COLLAR	1	
30	2K5-25118-00	COVER, hub dust	1	
31	353-25381-00	AXLE, wheel	1	
32	90171-10014	NUT, castle	1	
33	10V-25188-00	CAP	1	
34	91401-20020	PIN, cotter	1	
35	102-25137-00	RING, stop	1	
36	93210-14104	O-RING	1	

FWD
10V332-2270


D9

FIG. 28 REAR WHEEL



REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	10V-25311-00-98	HUB, rear	1	low gloss black
2	248-25317-00	SPACER, bearing	1	
3	148-25115-00	FLANGE, spacer 1	1	
4	93306-30203	BEARING (B6302Z)	1	
5	93306-20203	BEARING (B6202RS)	1	
6	93106-26005	OIL SEAL	1	
7	90116-10390	BOLT, stud	4	
8	4F2-25321-02-98	PLATE, brake shoe	1	low gloss black
9	3Y6-2533A-01	PLATE, indicator	1	
10	437-25330-01	BRAKE SHOE COMP.	2	
11	90506-16036	SPRING, tension	2	
12	10V-25355-00	LEVER, camshaft	1	
13	90101-06278	BOLT	1	
14	95601-06100	NUT, u	1	
15	2A6-25351-10	CAMSHAFT	1	
16	148-25359-00	SEAL, camshaft	1	
17	94418-18325	RIM (1.85-18)	1	
18	401-25304-10	SPOKE SET, rear	1	
19	94141-18780	TIRE (4.10-18)	1	
20	94241-18153	TUBE (4.10-18)	1	
21	94330-18087	BAND, rim (3.00-18)	1	
22	1T2-25394-00	SPACER, bead	1	
23	10V-25449-20	SPROCKET, driven (49T)	1	
24	10V-25412-00	WASHER	2	
25	90170-10219	NUT	4	
26	1W2-25388-01	PULLER, chain 1	1	
27	1W2-25389-01	PULLER, chain 2	1	
28	90387-157F0	COLLAR	1	

FIG. 28 REAR WHEEL




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	90387-157F0	COLLAR	1	
30	401-25367-00	COVER, hub dust	1	
31	2A6-25381-00	AXLE, wheel	1	
32	90'71-14029	NUT, castle	1	
33	4E7-25188-00	CAP	1	
34	90201-15238	WASHER, plate	1	
35	91401-30030	PIN, cotter	1	
36	94580-30118	CHAIN	1	
37	94680-30001	JOINT, chain	1	

10V332-2280

D11

FIG. 29 HANDLEBAR•CABLE




REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	10V-26111-00	HANDLEBAR	1	
2	1Y1-26290-50	BACK MIRROR ASSY (L•H)	1	
3	1Y1-26290-60	BACK MIRROR ASSY (R•H)	1	
4	434-26243-00	TUBE, throttle guide	1	
5	2N3-26242-00	GRIP (R•H)	1	
6	3G7-26249-00	RING, leaf	1	
7	2N3-26241-00	GRIP (L•H)	1	
8	10V-26311-00	CABLE, throttle 1	1	
9	10V-26312-00	CABLE, throttle 2	1	
10	10V-26321-00	CABLE, Pump	1	
11	3J0-26261-00	CONNECTOR, cable	1	
12	3J0-26262-00	CAP, cable connector	1	
13	360-26266-00	BOOT, cylinder	1	
14	3J0-26272-00	CAP	1	
15	2T5-26274-00	GUIDE, rotor	1	
16	2T5-26273-00	ROTOR	1	
17	2T5-26244-00	SLIDER, throttle	1	
18	2T5-26267-00	PIN	1	
19	90167-03004	SCREW, tapping	4	
20	90501-05512	SPRING, compression	1	
21	3J0-26393-00	HOLDER	1	
22	90170-10038	NUT	1	
23	10V-26335-00	CABLE, clutch	1	
24	382-26372-01	COVER, handle lever 1	1	
25	10V-26341-00	CABLE, brake	1	
26	498-26372-00	COVER, handle lever 1	1	
27	90123-08046	BOLT	2	
28	90179-08148	NUT	2	

10V332-2290

D12


FIG. 29 HANDLEBAR CABLE



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	2X1-26124-00	PROTECTOR, handlebar	1	
30	437-83936-10	BAND, switch cord	2	

10V332-2290

D13



10V332-2300


FIG. 30 STAND FOOTREST

REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	10V-27211-00	PEDAL, brake	1	
2	10V-27242-00	PEDAL, brake	1	
3	90508-20414	SPRING, torsion	1	
4	91701-08032	PIN, clevis	1	
5	92901-08600	WASHER, Plate	1	
6	90387-08762	COLLAR	1	
7	91401-25015	PIN, cotter	1	
8	10V-27216-01	SPRING, brake Pedal	1	
9	90201-12341	WASHER, Plate	1	
10	93430-03038	CIRCLIP	1	
11	97306-06020	BOLT	1	
12	95306-06700	NUT	1	
13	10V-27231-00	RCD, brake	1	
14	90240-06040	PIN, clevis	1	
15	92901-06200	WASHER, Plain	1	
16	91401-20015	PIN, cotter	1	
17	90501-10245	SPRING, compression	1	
18	90249-12008	PIN	1	
19	90175-06013	NUT, wing	1	
20	10V-27311-01	STAND, side	1	
21	90506-18224	SPRING, tension	1	
22	90506-26225	SPRING, tension	1	
23	90109-10649	BOLT	1	
24	3Y3-27315-00	LINK, side stand	1	
25	90185-10037	NUT, self-locking	1	
26	214-27421-00	FOOTREST 2	2	
27	214-27413-00	COVER, footrest	2	
28	90240-08084	PIN, clevis	2	

D14

FIG. 30 STAND-FOOTREST

REF. NO.	PART NO.	DESCRIPTION	QTY	REMARKS
29	91401-25015	PIN, cotter	2	
30	90F08-20023	SPRING, torsion	2	



FWD
10V332-2300

D15

CONTENTS

ENGINE

Cylinder Head - Cylinder	B2
Crankshaft - Piston	B3 ~ B4
C.D.I. Magneto	B5
Water Pump	B6
Radiator - Hose	B7
Oil Pump	B8 ~ B9
Intake	B10 ~ B11
Carburetor	B12 ~ B13
Exhaust	B14
Crankcase	B15
Crankcase Cover	C2
Kick Starter	C3
Clutch	C4
Transmission	C5 ~ C6
Shift Cam - Fork	C7
Shift Shaft - Pedal	C8

Rear Wheel	D10 ~ D11
Handlebar - Cable	D12 ~ D13
Stand - Footrest	D14 ~ D15
Cowling	E2
Turn Signal Light	E3
Meter	E4
Headlight	E5
Taillight	E6
Electrical 1	E7
Electrical 2	E8
Handle Switch - Lever	E9

INDEX

Numerical Index	M1 ~ M3
Parts Name Index	M10 ~ M16

CHASSIS

Frame - Tool	C9
Front Fender - Rear Fender	C10
Side Cover	C11
Oil Tank	C12
Rear Arm	C13 ~ C14
Rear Suspension	C15
Steering	D2
Front Fork	D3 ~ D5
Fuel Tank	D6
Seat	D7
Front Wheel	D8 ~ D9

CONTENTS

ENGINE

Cylinder Head - Cylinder	B2
Crankshaft - Piston	B3 ~ B4
C.D.I. Magneto	B5
Water Pump	B6
Radiator - Hose	B7
Oil Pump	B8 ~ B9
Intake	B10 ~ B11
Carburetor	B12 ~ B13
Exhaust	B14
Crankcase	B15
Crankcase Cover	C2
Kick Starter	C3
Clutch	C4
Transmission	C5 ~ C6
Shift Cam - Fork	C7
Shift Shaft - Pedal	C8

Rear Wheel	D10 ~ D11
Handlebar - Cable	D12 ~ D13
Stand - Footrest	D14 ~ D15
Cowling	E2
Flasher Light	E3
Meter	E4
Headlight	E5
Taillight	E6
Electrical 1	E7
Electrical 2	E8
Handle Switch - Lever	E9

INDEX


Numerical Index	M1 ~ M3
Parts Name Index	M10 ~ M16

CHASSIS

Frame - Tool	C9
Front Fender - Rear Fender	C10
Side Cover	C11
Oil Tank	C12
Rear Arm	C13 ~ C14
Rear Suspension	C15
Steering	D2
Front Fork	D3 ~ D5
Fuel Tank	D6
Seat	D7
Front Wheel	D8 ~ D9

FIG. 31 COWLING


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-28351-00-G8	BODY, cowl up	1	UR sky blue
	10V-28351-00-33	BODY, cowl ing	1	UR yamaha black
	10V-28351-00-36	BODY, cowl g	1	UR clean white
2	97306-06025	BOLT	1	
3	92906-06100	WASHER, spring	1	
4	90480-14023	GROMMET	1	
5	90387-067F1	COLLAR	1	
6	97306-06030	BOLT	2	
7	90480-14331	GROMMET	2	
8	90387-060G8	COLLAR	2	
9	10V-28356-00	STAY 1	1	
10	95801-06010	BOLT, flange	1	
11	10V-28368-00	EMBLEM	1	



10V351-2310


E2

FIG. 32 FLASHER LIGHT



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12V-83310-10	FRONT FLASHER LIGHT ASSY 1	2	
2	5Y1-83312-00	•LENS, flasher	1	
3	*	•BULB (6V-21W)	1	LM
4	5Y1-83313-00	•GASKET, flasher lens	1	
5	98503-04010	•SCREW, Pan head	1	
6	97701-40530	•SCREW, tapping	1	
7	95702-12100	NUT, flange	2	
8	10V-83365-00	CAP	2	
9	10V-83318-00	STAY, flasher 1	1	
10	10V-83328-00	STAY, flasher 2	1	
11	10V-83330-40	REAR FLASHER LIGHT ASSY 1	2	
12	10V-83312-00	•LENS, flasher	1	
13	*	•BULB (6V-21W)	1	LM
14	5Y1-83313-00	•GASKET, flasher lens	1	
15	98503-04010	•SCREW, Pan head	1	
16	97701-40530	•SCREW, tapping	1	
17	95702-12100	NUT, flange	2	
18	10V-83365-00	CAP	2	
19	10V-83368-00	STAY, flasher	1	
20	10V-83369-00	STAY, flasher	1	
21	95806-08012	BOLT, flange	2	

FIG. 33 METER




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-83570-F0	SPEEDOMETER ASSY	1	km/h
2	15A-83536-00	•SOCKET, meter	1	
3	122-83516-10	•BULB (6V-3W)	1	
4	10V-83590-00	WATER TEMPERATURE ASSY	1	
5	10V-83520-00	•SOCKET CORD ASSY	1	
6	122-83516-10	•BULB (6V-3W)	5	
7	92903-03100	•WASHER, spring	3	
8	95301-03700	•NUT	3	
9	10V-83541-00	DAMPER	1	
10	10V-83519-00	BRACKET, meter	1	
11	5Y1-83513-00	DAMPER	1	
12	1M1-83526-00	DAMPER 2	3	
13	9020 -05033	WASHER, Plate	3	
14	437-83525-00	CLIP	3	
15	95806-06040	BOLT, flange	2	
16	95706-06100	NUT, flange	2	
17	10V-83550 00	SPEEDOMETER CABLE ASSY	1	

10V351-2330

E4

FIG. 34 HEADLIGHT




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-84103-40	HEADLIGHT UNIT ASSY	1	
2	10V-84115-00	•RIM, headlight	1	
3	10V-84120-40	•LENS ASSY	1	
4	10V-84331-00	•SCREW, rim adjusting	2	
5	233-84127 60	•WASHER, special	2	
6	341-84332-60	•SPRING, screw	2	
7	198-84334-60	•NUT, adjusting	2	
8	5G2-84324-A0	•SPRING, reflector	1	
9	306-84346-30	•SOCKET, Pilot light	1	
10	*	•BULB (6V-45/40W)	1	LM
11	*	•BULB (5V-4W)	1	LM
12	90159-06033	SCREW, with washer	3	



10V351-2340

E5


FIG. 35 TAILLIGHT



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-84510-40	TAILLIGHT UNIT ASSY	1	
2	1M3-84514-41	•BULB (6V 21/5W)	1	
3	10V-84521-00	•LENS, taillight	1	
4	10V-84520-40	•TAILLIGHT BASE ASSY	1	
5	10V-84523-00	•GASKET, lens	1	
6	97701-40540	•SCREW, tapping	2	
7	10V-84517-00	CORD, taillight	1	
8	10V-84527-00	DAMPER	1	
9	90387-07391	COLLAR	2	
10	95601-06100	NUT, u	2	
11	449-85131-01	REFLECTOR, rear 1	1	
12	90201-C5031	WASHER, Plate	1	
13	95302-05600	NUT	1	
14	92902-05100	WASHER, sPring	2	

10V361-2350

E6




10V332-2360

FIG. 36 ELECTRICAL 1

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	10V-82310-40	IGNITION COIL ASSY	1	
2	92502-06025	SCREW, Pan head	2	
3	92902-06100	WASHER, sPring	2	
4	1M1-82370-21	PLUG CAP ASSY	1	
5	1E6-82110-12	BATTERY ASSY	1	
6	90445-08425	HOSE	1	
7	10V-82124-00	BAND, battery	1	
8	10V-82131-00	BAND, battery	1	
9	10V-82136-00	PLATE, battery fitting	1	
10	1M1-82115-00	WIRE, Plus lead	1	
11	558-82116-00	WIRE, minus lead	1	
12	353-82150-00	FUSE HOLDER ASSY	1	
13	116-82151-00	•FUSE (6V-10A)	1	
14	10V-82508-45	MAIN SWITCH ASSY	1	
15	2H1-82555-00	•DAMPER, main switch 1	1	
16	437-82516-00	•COLLAR, main switch	2	
17	437-82556-00	•DAMPER, main switch	2	
18	98501-05025	SCREW, Pan head	2	
19	92902-05100	WASHER, sPring	2	
20	90201-05033	WASHER, Plate	2	
21	10V-82530-00	STOP SWITCH ASSY	1	
22	341-82540-01	NEUTRAL SWITCH ASSY	1	
23	10V-82590-40	WIRE HARNESS ASSY	1	
24	90464-20031	CLAMP	1	
25	2E7-85720-02	OIL LEVEL GAUGE ASSY	1	

E7

FIG. 37 ELECTRICAL 2




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2A8-83350-40	FLASHER RELAY ASSY	1	
2	2A7-83371-10	HORN	1	
3	95801-06010	BOLT, flange	2	
4	10V-83591-00	THERMO UNIT	1	
5	90430-10164	GASKET	1	
6	10V-85540-20	C.D.I. UNIT ASSY	1	
7	2A7-85546-00	BAND	1	
8	10V-81910-60	VOLTAGE REGULATOR ASSY	1	
9	92501-06012	SCREW, Pan head	2	
10	92902-06600	WASHER	2	
11	353-81970-50	RECTIFIER ASSY	1	
12	98501-05020	SCREW, Pan head	1	
13	92901-05600	WASHER, Plate	1	



10V332-2370

E8

FIG. 36 HANDLE SWITCH-LEVER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	493-82911-00	HOLDER, lever 1	1	
2	511-83912-00	LEVER 1	1	
3	90109-06576	BOLT	1	
4	90201-082A9	WASHER, Plate	1	
5	95606-06100	NUT, u	1	
6	97306-06020	BOLT	1	
7	92906-06100	WASHER, sPring	1	
8	361-82921-31	HOLDER, lever 2	1	
9	5Y1-83922-00	LEVER 2	1	
10	90109-06576	BOLT	1	
11	90201-082A9	WASHER, Plate	1	
12	95606-06100	NUT, u	1	
13	97306-06020	BOLT	1	
14	92906-06100	WASHER, sPring	1	
15	1M1-83980-30	FRONT STOP SWITCH ASSY	1	
16	1R6-83976-01	SWITCH, handle 1	1	
17	90157-05027	•SCREW, Pan head	2	
18	437-83936-00	BAND, switch cord	2	
19	10V-83972-00	SWITCH, handle 4	1	
20	98501-05030	•SCREW, Pan head	1	
21	98501-05035	•SCREW, Pan head	1	
22	437-83936-00	BAND, switch cord	2	



10V351-2380

E9

CONTENTS

ENGINE

Cylinder Head - Cylinder	B2
Crankshaft - Piston	B3 ~ B4
C.D.I. Magneto	B5
Water Pump	B6
Radiator - Hose	B7
Oil Pump	B8 ~ B9
Intake	B10 ~ B11
Carburetor	B12 ~ B13
Exhaust	B14
Crankcase	B15
Crankcase Cover	C2
Kick Starter	C3
Clutch	C4
Transmission	C5 ~ C6
Shift Cam - Fork	C7
Shift Shaft - Pedal	C8

CHASSIS

Frame - Tool	C9
Front Fender - Rear Fender	C10
Side Cover	C11
Oil Tank	C12
Rear Arm	C13 ~ C14
Rear Suspension	C15
Steering	D2
Front Fork	D3 ~ D
Fuel Tank	D6
Seat	D7
Front Wheel	D8 ~ D9

Rear Wheel	D10 ~ D11
Handlebar - Cable	D12 ~ D13
Stand - Footrest	D14 ~ D15
Cowling	E2
Flasher Light	E3
Meter	E4
Headlight	E5
Taillight	E6
Electrical 1	E7
Electrical 2	E8
Handle Switch - Lever	E9

INDEX

Numerical Index	M1 ~ M3
Parts Name Index	M10 ~ M16

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.
10V-W24-22-10	D 7	107-13137-00-05	B 8
10V-W24-22-10	D 7	107-13137-00-05	B 8
10V-W4451-00	B 10	137-13138-01	B 8
10V-11111-00	B 2	278-13169-00	B 8
10V-11181-00	B 2	10V-13174-00	B 9
10V-1131E-00	B 2		
10V-11311-00	B 2	10V-13175-00	B 8
10V-11351-00	B 2	137-13176-00	B 8
10V-11400-00	B 3	10V-13178-00	B 8
10V-11412-00	B 3	10V-13416-00	B 8
10V-11422-00	B 3	353-13552-01	B 8
10V-11454-00	B 4	10V-13565-00	B 10
10V-11531-01	B 4	10V-13581-00	B 10
10V-11536-00	B 3	10V-13584-00	B 10
10V-11610-00	B 3	10V-13610-00	B 10
10V-11610-10	B 3	10V-13613-00	B 10
10V-11610-20	B 3	10V-13616-00	B 10
10V-11610-30	B 3	311-13621-01	B 10
10V-11610-40	B 3	10V-14101-00	B 12
10V-11631-00-9C	B 3	211-14112-20	B 12
137-11633-00	B 3	500-14115-00	B 12
10V-11635-00	B 3	166-14116-13	B 12
10V-11636-00	B 3	443-14122-00	B 12
10V-11637-00	B 3	525-14123-00	B 13
10V-11638-00	B 3	245-14131-00	B 13
3R2-11651-01	B 3	493-14133-00	B 12
3M5-11681-00	B 3	174-14134-00	B 13
10V-12422-00	B 6	2Y1-14136-00	B 13
10V-12426-00	B 6	164-14137-00	B 12
10V-12428-00	B 6	363-14137-00	B 13
10V-12436-00	B 6	2F5-14141-42	B 12
10V-12446-00	B 6	260-14142-20	B 12
10V-12450-00	B 6	137-14143-15	B 12
10V-12459-00	B 6	137-14143-16	B 12
10V-12460-00	B 7	137-14143-17	B 12
4L0-12462-00	B 7	2N4-14145-00	B 12
10V-12464-00	B 7	214-14147-00	B 12
10V-12465-00	B 7	354-14147-00	B 13
10V-12467-01	B 7	351-14147-00	B 13
10V-12467-11	B 7	558-14147-00	B 12
10V-12467-21	B 7	1T9-14155-00	B 12
10V-12469-00	B 7	10V-14158-00	B 13
10V-12481-00	B 7	127-14161-00	B 12
10V-12482-00	B 7	3X3-14169-00	B 12
10V-13101-00	B 8	4U5-14171-00	B 12
353-13115-01	B 15	4E9-14184-00	B 12
126-13116-00	B 8	314-14185-00	B 12
363-13133-01	B 8		

PART NO.	GRID NO.	PART NO.	GRID NO.
127-14186-00	B 12	10V-16351-00	C 4
168-14190-25	B 12	1W1-16356-01	C 4
214-14195-00	B 12	4V0-16357-00	C 4
183-14197-01	B 13	1W1-16358-00	C 4
3X3-14197-00	B 12	4V2-16371-00	C 4
508-14198-00	B 13	10V-16380-00	C 4
509-14274-00	B 13	2A6-17121-00	C 5
10V-14411-00	B 10	5V7-17131-00	C 5
10V-14412-00	B 10	5V7-17151-00	C 5
10V-14421-00	B 10	10V-17161-00	C 5
10V-14437-00	B 10	5V7-17211-00	C 5
10V-14452-00	B 10	5V7-17221-00	C 5
10V-14453-00	B 11	5V7-17231-00	C 5
10V-14468-00	B 10	5V7-17241-00	C 5
10V-14476-00	B 10	10V-17251-00	C 5
10V-14477-00	B 11	10V-17261-00	C 5
10V-14510-01	B 14	10V-17411-00	C 5
152-14613-00	B 14	10V-17421-00	C 5
152-14714-00	B 14	164-17427-00-10	C 5
10V-14718-01	B 14	5H0-17456-00	C 5
10V-14747-00	B 14	5H0-17461-50	C 5
10V-14753-00	B 14	10V-17471-00	C 5
10V-14758-00	B 14	10V-18101-00	C 8
135-14771-00	B 14	10V-18110-00	C 8
10V-15111-00	B 15	1W6-13113-00	C 3
10V-15121-00	B 15	10V-18110-00	C 7
10V-15128-00	B 15	1W1-18177-00	C 7
3Y1-15361-00	C 2	5R2-18185-00	C 7
3Y1-15363-00	C 2	10-18511-00	C 7
10V-15411-00	C 2	3R3-18512-00	C 7
10V-15416-00	C 2	10V-18513-00	C 7
10V-15421-00	C 2	3R4-18531-00	C 7
10V-15451-00	C 2	10V-18535-00	C 7
10V-15456-00	C 2	10V-18540-00	C 7
156-15618-01	C 3	136-18542-00	C 7
10V-15620-00	C 3	3R4-18561-00	C 7
10V-15621-00	C 3	10V-21110-40-33	C 9
10V-15641-00	C 3	5A8-21308-00	C 9
10V-15651-00	C 3	10V-21471-00	C 9
10V-15660-00	C 3	2K7-21484-00	C 9
10V-15666-00	C 3	10V-21485-00	C 9
246-16111-00	C 4	10V-21511-00	C 10
10V-16150-00	C 4	10V-21511-10	C 10
10V-16154-00	C 4	10V-21511-20	C 10
4V0-16154-00	C 4	10V-21611-00	C 10
10V-16321-00	C 4	10V-21611-10	C 10
1V1-16324-00	C 4	10V-21611-20	C 10
		10V-21621-00	C 10

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.
10V-21685-10	C 10	10V-23125-00	D 3
10V-21691-00	C 10		D 4
10V-21711-00	C 11	10V-23130-00	D 3
10V-21711-10	C 11	10V-23135-00	D 3
10V-21711-20	C 11		D 4
10V-21717-00	C 11	10V-23140-00	D 3
10V-21721-00	C 11	10V-23141-00	D 3
10V-21721-10	C 11		D 4
10V-21721-20	C 11	10V-23142-00	D 3
10V-21745-00	C 12		D 4
10V-21751-00	C 12	10V-23144-00	D 3
4U5-2176E-00	C 11		D 4
10V-2177A-00	C 11	10V-23145-00	D 3
10V-21771-00	C 12		D 4
10V-21781-01	C 11	10V-23147-00	D 3
10V-21781-10	C 11		D 4
10V-21875-00	C 12	10M-23151-00	D 3
10V-21876-00	C 12		D 4
10V-21877-00	C 12	1J3-23156-00	D 3
10V-22110-00-35	C 13		D 4
401-22127-00	C 13	2F3-23157-00	D 3
1W1-22128-00	C 15		D 4
401-22128-01	C 13	10V-23166-00	D 3
3J0-22131-00	C 14		D 4
434-22141-00	C 13	1J3-23168-00	D 3
10V-22147-00	C 14		D 4
10V-22151-00	C 13	10V-23171-00	D 3
10V-22153-00	C 13		D 4
10V-22171-00	C 9	3M7-23181-00	D 3
2N0-22176-00	C 13		D 4
10V-22179-00	C 13	1J3-23183-01	D 3
10V-22184-00	C 9		D 4
10V-22187-00	C 13	10V-23191-00	D 3
10V-22210-00	C 15		D 4
1W1-22216-00	C 15	10V-23192-00	D 3
3R4-22226-00	C 15		D 4
10V-22311-00	C 13	10V-2331E-00	D 4
10V-22312-00	C 13	10V-23317-00	D 2
10V-23102-00	D 3	10V-23318-00	D 2
10V-23103-00	D 3	10V-23319-00	D 4
10V-23110-00	D 3	3Y1-23319-00	D 2
	D 4	10V-23340-30-90	D 4
1T4-23111-00	D 3	10V-23346-00	D 4
	D 4	10V-23351-00	D 3
2F3-23114-00	D 3		D 4
	D 4	1W1-23389-00	D 2
2A6-23119-00	D 3		D 5
	D 4	10V-233P0-00	D 2

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.
462-23392-02	D 3	102-25137-00	D 9
122-23411-00	D 2	248-25138-11	D 8
156-23411-00	D 2	183-25149-00	D 8
122-23412-00	D 2	2N4-25155-00	D 8
156-23412-00	D 2	10V-25188-00	D 9
583-23416-01	D 2	4E7-25188-00	D11
10V-23435-00-98	D 2	401-25304-10	D10
1E6-23441-00-98	D 2	10V-25311-00-98	D10
164-23462-00	D 2	109-25315-00	D 8
10V-24110-00-01	D 6	248-25317-00	D10
10V-24110-00-02	D 6	4F2-25321-02-98	D10
10V-24110-00-03	D 6	3Y6-2533A-01	D 8
10V-24181-00	C11		D10
278-24181-00	D 6	437-25330-01	D 8
431-24181-00	C 9		D10
	C11	2A6-25351-10	D10
10V-24182-00	D 6	248-25351-10	D 8
4U5-24182-00	D 6	10V-25355-00	D10
10V-24183-00	D 6	148-25350-00	D10
10V-24186-00	D 6	401-25367-00	D11
10V-24240-00	D 6	2A6-25381-00	D11
10V-24240-10	D 6	353-25381-00	D 9
10V-24240-20	D 6	1W2-25388-01	D10
10V-24500-00	D 6	1W2-25389-01	D10
4X8-24512-00	D 6	1T2-25394-00	D10
4X8-24515-01	D 6	10V-25412-00	D10
4X8-24534-00	D 6	10V-25449-20	D10
4X8-24535-00	D 6	10V-26111-00	D12
4X8-24565-00	D 6	2X1-26124-00	D13
3Y1-24610-01	D 6	2N3-26241-00	D12
214-24724-00	D 7	2N3-26242-00	D12
509-24724-00	D 7	434-26243-00	D12
10V-24728-00	D 7	2T5-26244-00	D12
10V-24731-20	D 7	3G7-26249-00	D12
10V-24731-30	D 7	3J0-26261-00	D12
10V-24738-10	D 7	3J0-26262-00	D12
10V-24748-10	D 7	360-26266-00	D12
10V-24754-00	D 7	2T5-26267-00	D12
10V-24773-00	D 7	3J0-26272-00	D12
10V-24774-00	D 7	2T5-26273-00	D12
10V-24776-00	D 7	2T5-26274-00	D12
2A6-25104-00	D 8	1Y1-26290-50	D12
2A6-25111-00-98	D 8	1Y1-26290-60	D12
148-25115-00	D10	10V-26311-00	D12
2K5-25118-00	D 9	10V-26312-00	D12
4F2-25110-00-98	D 8	10V-26321-00	D12
243-25135-11	D 8	10V-26335-00	D12
10V-25136-00	D 8	10V-26341-00	D12

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.
382-26372-01	D12	*	E 3	10V-84527-10	E 6	30179-0140	D12
498-26372-00	D12	10V-83312-00	E 3	449-85131-0	E 6	90179-06210	B14
3J0-26393-00	D12	5Y1-83312-00	E 3	10V-85500-20	B 5	90179-08290	B 2
371-27114-00	D 7	5Y1-83313-00	E 3	10V-85512-20	B 5	90179-12101	B 4
10V-27211-00	D14	10V-83318-00	E 3	10V-85513-20	B 5	90179-12240	C 4
10V-27216-01	D14	10V-83328-00	E 3	10V-85514-20	B 5	90179-12374	C 3
10V-27231-00	D14	10V-83330-40	E 3	10V-85515-20	B 5	90179-20033	D 2
10V-27242-00	D14	2A8-83350-40	E 8	10V-85540-20	E 8	90183-00004	D 7
10V-27311-01	D14	10V-83365-00	E 3	2A7-85546-00	E 8	90185-08009	C 9
3Y3-27315-00	D14	10V-83368-00	E 3	10V-85550-20	B 5	90185-10037	D14
214-27413-00	D14	10V-83369-00	E 3	10V-85561-20	B 5	90185-12046	C13
214-27421-00	D14	2A7-83371-10	E 8	2E7-85720-02	E 7	90201-044A2	C10
120-27430-02	C13	5Y1-83513-00	E 4	90101-06278	D 8		E 6
120-27431-00	C14	122-83516-10	E 4		D10	90201-05031	E 6
120-27432-02	C13	10V-83519-00	E 4	90101-06304	D 7		
120-27433-00	C13	10V-83520-00	E 4	90105-08219	D 2	90201-05033	E 4
0V-28100-10	C 9	437-83525-00	E 4	90105-08221	C 9		E 7
10V-28110-00	C 9	1M1-83526-00	E 4	90105-08222	C 9	90201-062A8	E 1
10V-28135-00	C 9	15A-83536-00	E 4	90105-14102	D 2	90201-06557	C 0
10V-28351-00-98	E 2	10V-83541-00	E 4	90109-06576	E 9	90201-06570	B
10V-28351-00-33	E 2	10V-83550-00	E 4	90109-08661	C13	90201-07076	D 1
10V-28351-00-36	E 2	10V-83570-00	E 4	90109-10649	D14	90201-08113	C 9
10V-28356-00	E 2	10V-83590-00	E 4	90109-10662	C15	90201-082A9	E 9
10V-28368-00	E 2	10V-83591-00	E 8	90116-08042	B14	90201-08512	B 5
10V-81328-20	B 5	5Y1-83912-00	E 9	90116-08318	B 2	90201-08624	B 8
104-81328-20	B 5	5Y1-83922-00	E 9	90116-08388	B 2	90201-08649	B 2
10V-81910-60	E 8	437-83936-00	E 9	90116-08391	B 2	90201-122F8	B15
353-81970-50	E 8	437-83936-10	D13	90116-10390	D10	90201-12541	D14
1E6-82110-12	E 7	10V-83972-00	E 9	90119-05001	C 4	90201-12593	B 5
1M1-82115-00	E 7	1R6-83976-01	E 9	90119-05062	C13	90201-127E0	C 3
558-82116-00	E 7	1M1-83980-30	E 9	90119-05067	C14	90201-14217	C 4
10V-82124-00	E 7	10V-84103-40	E 5	90119-06043	C11	90201-15238	D11
10V-82131-00	E 7	*	E 5	90119-06056	B10	90201-154E8	C 3
10V-82136-00	E 7	10V-84115-00	E 5	90119-06061	C10	90201-202F9	C 3
353-82150-00	E 7	10V-84120-40	E 5	90119-06063	C10	90201-20266	C 5
116-82151-00	E 7	233-84127-60	E 5	90123-08046	D12	90201-20269	D 8
10V-82310-40	E 7	*	E 5	90146-06012	C11	90201-20279	C14
1M1-82370-21	E 7	5G2-84324-A0	E 5	90149-06011	D 6	90201-203F0	C 7
10V-82508-45	E 7	10V-84331-00	E 5	90154-05013	B 7	90201-22555	C 5
437-82516-00	E 7	341-84332-60	E 5	90157-05027	E 9	90202-06010	B14
10V-82530-00	E 7	198-84334-60	E 5	90159-06033	E 5		D 6
341-82540-01	E 7	306-84346-30	E 5	90167-03004	D12	90204-12007	C 4
2H1-82555-00	E 7	10V-84510-40	E 6	90170-10038	D12	90208-17032	C 4
437-82556-00	E 7	1M8-84514-41	E 6	90170-10219	D10	90209-06187	C10
10V-82590-40	E 7	10V-84517-00	E 6	90170-12060	C 4	90209-18135	C 5
498-82911-00	E 9	10V-84520-40	E 6	90170-12067	B 5	90209-22071	B 3
361-82921-31	E 9	10V-84521-00	E 6	90171-10014	D 9	90215-12007	C 4
12V-83310-10	E 3	10V-84523-00	E 6	90171-14029	D11	90215-15200	B 4
				90175-06013	D14		

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.
90240-06009	C 4	90465-14202	C 2
90240-06040	D 4	90467-08003	B 9
90240-08084	D 14		C 12
90240-12092	C 15		D 6
90249-12008	D 14	90467-10008	C 12
90250-06013	C 7	90467-20050	B 10
90267-40029	C 10	90467-21058	B 7
			B 10
90280-03017	B 3	90467-23067	B 7
90282-04036	C 7	90468-02033	B 8
90282-05013	B 4	90468-15020	B 8
90282-05047	B 3	90468-26048	C 3
90338-05038	B 15	90480-01141	C 11
90338-09130	D 8	90480-01209	B 15
90338-16015	B 15	90480-01326	B 14
90340-12059	B 15	90480-01327	B 7
90380-12051	C 15	90480-10070	B 7
90386-18028	C 13	90480-12325	C 11
90387-05682	C 14	90480-14023	C 9
90387-06068	E 2		C 12
90387-067F1	E 2		E 2
90387-072E7	B 7	90480-14331	E 2
90387-07391	C 9	90480-15064	B 7
	C 12	90480-18324	C 11
	E 6	90501-05512	D 12
90387-077F4	B 14	90501-10245	D 14
90387-07762	D 14	90501-12081	C 3
90387-07265	D 9	90501-20122	C 4
90387-127F2	C 13	90506-16036	D 8
90387-157F0	D 10		D 10
	D 11	90506-18224	D 14
90387-207F3	B 3	90506-26225	D 14
90430-04004	B 8	90508-20023	D 14
90430-06166	B 2	90508-20414	D 14
	B 6	90508-20555	C 4
90430-10164	E 8	90508-26554	C 7
90430-12038	B 15	90508-26556	C 3
90445-05217	B 8	90508-32553	C 8
90445-08425	E 7	90508-35552	C 13
90445-09082	B 15	90560-12138	D 3
90445-09097	D 6	91401-16015	C 14
		91401-20015	D 14
90460-37026	B 14	91401-20020	D 9
90460-44108	B 10	91401-25015	D 14
90460-49058	B 11		D 15
90462-05005	B 10	91401-30025	C 15
90462-12105	B 15	91401-30030	D 11
90464-20031	E 7	91701-08032	D 14
		91810-02014	C 2

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.
93003-22028	B 8	95826-06010	B 2
93604-07141	C 4	95826-06030	C 2
93604-10011	B 6	97301-06012	D 6
94127-21779	D 8	97301-06022	C 12
94141-18780	D 10	97301-06025	C 9
94227-21123	D 8		
94241-18153	D 10	97306-06020	D 14
94330-18087	D 10		E 9
94330-21084	D 8	97306-06025	B 7
94416-21310	D 8		B 10
94418-18325	D 10		E 2
94580-30118	D 11		E 2
94680-30001	D 11	97306-06030	C 5
94701-00204	B 2	97321-06010	C 8
95301-03700	E 4	97321-06020	B 10
95301-05600	B 8	97602-03108	B 12
95301-03700	C 13		B 10
95301-06600	C 4	97701-40516	E 3
95301-08800	B 2	97701-40530	E 6
95301-12700	C 14	97701-40540	B 5
95302-05600	E 6	98501-04008	B 12
		98501-04016	B 5
95306-06700	D 14	98501-04010	B 8
95601-06100	C 10	98501-05016	E 8
	D 8	98501-05020	E 7
	D 10	98501-05025	E 9
	E 6	98501-05030	C 13
95602-10100	C 15	98501-05035	E 9
95606-06100	E 9		E 9
95606-08100	C 9	98502-04035	E 3
95702-12100	E 3	98503-04010	C 7
95706-06100	E 4	98701-05016	B 8
95801-06010	D 2	98901-04008	B 14
	E 2	98906-06010	B 7
	E 5	98906-06020	B 2
	E 8	*	
95801-06016	C 11		
95801-06050	C 13		
95801-08012	B 7		
95806-06010	D 2		
95806-06012	B 14		
	D 2		
95806-06040	E 4		
95806-08012	B 14		
	E 3		
95806-08016	D 7		
95806-08050	C 9		
95821-06010	B 6		

PARTS NAME INDEX

DESCRIPTION	GRID NO.
ARM, tensioner	C13
AXLE, drive	C 5
AXLE, main	C 5
AXLE, wheel	D 9
*	D11
BACK MIRROR ASSY (L.H)	D12
BACK MIRROR ASSY (R.H)	D12
BALL	B 8
*	C 3
*	C 4
*	D 2
*	D 2
BAND	C 9
*	D 3
*	D 4
*	E 8
BAND, battery	E 7
*	E 7
BAND, rim (3.00-18)	D10
BAND, rim (3.00-21)	D 8
BAND, switch cord	D13
*	E 9
*	E 9
BAR, shift fork Guide 1	C 7
BAR, shift fork Guide 2	C 7
BASE, magneto	B 5
BATTERY ASSY	E 7
BEARING	C 7
BEARING (B6202RS)	D10
BEARING (B6204CS)	C 5
BEARING (B6205C4)	B 3
BEARING (B6301)	D 8
BEARING (B6302)	B 4
BEARING (B6302Z)	D10
BEARING (B6303)	B 4
BEARING (B6303Z)	C 5
BEARING (B6304C3)	B 3
BEARING, cylindrical	B 3
*	B 3
*	C 5
*	C 5
BODY, cap	C12
BODY, cowling	E 2
*	E 2

PARTS NAME INDEX

DESCRIPTION	GRID NO.
BODY, cowling	E 2
BOLT	B 7
*	B10
*	B14
*	C 5
*	C 8
*	C 9
*	C12
*	C13
*	C14
*	C15
*	D 6
*	D 7
*	D 8
*	D10
*	D12
*	D14
*	D14
*	E 2
*	E 2
*	E 9
*	E 9
*	E 9
*	E 9
BOLT 1	D 4
BOLT, fange	B 2
*	B 6
*	B 7
*	B14
*	B14
*	C 9
*	C11
*	C13
*	D 2
*	D 2
*	D 2
*	D 2
*	D 7
*	E 2
*	E 3
*	E 4
*	E 8
BOLT, hexagon socket head	D 3
*	D 4
BOLT, stopper	C 7
BOLT, stud	B 2
*	B 2

PARTS NAME INDEX

DESCRIPTION	GRID NO.
BOLT, stud	B 2
*	B14
*	D10
BOLT, washer based	C 9
*	C 9
*	D 2
*	D 2
BOLT, with washer	B10
*	C 4
*	C10
*	C10
*	C10
*	C11
*	C13
*	C13
*	C13
*	C14
BOOT	D 3
*	D 4
BOLT, cylinder	D 2
BOSS, clutch	C 4
BOSS, kick crank	C 2
BOX	C11
BRACKET 1	C13
BRACKET, license	C10
BRACKET, meter	E 4
BRACKET, seat	D 7
*	D 7
*	D 7
BRAKE SHOE COMP.	D 8
*	D10
BULB (6V 21/5W)	E 6
BULB (6V-21W)	E 3
*	E 3
BULB (6V-3W)	E 4
*	E 4
BULB (6V-4W)	E 5
BULB (6V-45/40W)	E 5
BUSH	C 9
*	C13
*	D 8
BUSH, rear shock absorber	C15
BUSH, shock absorber lower	C15
BUSH, solid	C15
C.D.I. MAGNETO ASSY	B 5
C.D.I. UNIT ASSY	E 8
CABLE, brake	D12
CABLE, clutch	D12
CABLE, pump	D12
CABLE, throttle 1	D12

PARTS NAME INDEX

DESCRIPTION	GRID NO.
CABLE, throttle 2	D12
CAMSHAFT	D 8
*	D10
CAP	B12
*	C12
*	D 9
*	D11
*	D12
*	E 3
*	E 3
CAP ASSY	D 6
CAP, cable connector	D12
CAP, cleaner case 1	B10
CAP, front fork	D 3
*	D 4
CAP, radiator	B 7
CARBURETOR ASSY 1	B12
CASE, air cleaner 1	B10
CASE, air cleaner 2	B10
CASE, chain	C13
CASE, chain 2	C13
CHAIN	D11
CHAMBER, air	B10
CIRCLIP	B 3
*	B 6
*	B 8
*	C 3
*	C 3
*	C 5
*	C 5
*	C 5
*	C 7
*	C 8
*	D 7
*	D 8
*	D14
CLAMP	B 5
*	B 5
*	B10
*	B15
*	C 2
*	E 7
CLAMP, hose	B10
*	B11
*	B14
CLIP	B 7
*	B 7
*	B 8

PARTS NAME INDEX

DESCRIPTION	GRID NO.
CLIP	B 8
*	B 8
*	B 8
*	B 9
*	B10
*	B10
*	B10
*	B12
*	B13
*	C 3
*	C12
*	C12
*	C12
*	D 6
*	E 4
CLIP, oil seal	D 3
*	D 4
CLUTCH, meter	D 8
COIL, lighting 1	B 5
COIL, lighting 2	B 5
COIL, source	B 5
COLLAR	B 3
*	B 7
*	B14
*	C 9
*	C12
*	C13
*	C14
*	D 9
*	D10
*	D11
*	D14
*	E 2
*	E 2
*	E 6
COLLAR, main switch	E 7
CONNECTOR	B13
CONNECTOR, cable	D12
CONNECTOR, suction pipe	B15
CORD, taillight	E 6
COVER, ball race 2	D 2
COVER, crankcase 1	C 2
COVER, crankcase 2	C 2
COVER, double seat	D 7
*	D 7
COVER, footrest	D14
COVER, handle lever 1	D12
*	D12

PARTS NAME INDEX

DESCRIPTION	GRID NO.
COVER, housing	B 6
COVER, hub dust	D 9
*	D11
COVER, kick lever	C 3
COVER, oil pump	C 2
COVER, radiator	B 7
*	B 7
*	B 7
COVER, rear footrest	C13
COVER, shift pedal	C 8
COVER, side 1	C11
*	C11
*	C11
COVER, side 2	C11
*	C11
*	C11
COVER, thrust 1	C15
CRANK 1	B 3
CRANK 2	B 3
CRANKCASE 1	B15
CRANKCASE 2	B15
CRANKSHAFT ASSY	B 3
CROWN, handle	D 2
CYLINDER 1	B 2
DAMPER	E 4
*	E 4
*	E 6
DAMPER 2	E 4
DAMPER, locating 1	C 9
*	C11
*	C11
*	D 6
DAMPER, locating 2	D 6
*	D 6
DAMPER, locating 3	D 6
DAMPER, main switch	E 7
DAMPER, main switch 1	E 7
DAMPER, muffler	B14
DAMPER, radiator	B 7
DAMPER, rubber 1	C 9
DAMPER, seat	D 7
*	D 7
DAMPER, side cover	C11
DOUBLE SEAT ASSY	D 7
*	D 7
DUCT	B10
ELEMENT, SET	B10
EMBLEM	E 2
EMBLEM 1	C11

PARTS NAME INDEX

DESCRIPTION	GRID NO.
EMBLEM 1	C11
EXHAUST PIPE ASSY 1	B14
FENDER, front	C10
*	C10
*	C10
FENDER, rear	C10
*	C10
*	C10
FLANGE, sPacer	D 8
FLANGE, sPacer 1	D10
FLAP	C10
*	C10
FLASHER RELAY ASSY	E 8
FLOAT	B12
FOOTREST 2	D14
FOOTREST, rear 1	C14
FORK UNIT ASSY	D 3
FORK UNIT ASSY 2	D 3
FORK, shift 1	C 7
FORK, shift 2	C 7
FORK, shift 3	C 7
FRAME COMP	C 9
FRONT FLASHER LIGHT ASSY 1	E 3
FRONT FORK ASSY (L.H)	D 3
FRONT FORK ASSY (R.H)	D 3
FRONT STOP SWITCH ASSY	E 9
FUEL COCK ASSY 1	D 6
FUEL TANK COMP.	D 6
*	D 6
*	D 6
FUSE (6V-10A)	E 7
FUSE HOLDER ASSY	E 7
GASKET	B 2
*	B 6
*	B 8
*	B13
*	B15
*	D 3
*	D 4
*	D 6
*	D 6
*	E 8
GASKET 1	C 2
GASKET, crankcase cover	C 2
GASKET, cylinder	B 2
GASKET, cylinder head 1	B 2
GASKET, exhaust PiPe	B14
GASKET, flasher lens	E 3

PARTS NAME INDEX

DESCRIPTION	GRID NO.
GASKET, flasher lens	E 3
GASKET, float chamber	B12
GASKET, housing cover 2	B 6
GASKET, lens	E 6
GASKET, muffler	B14
GASKET, oil Pump cover 1	C 2
GASKET, Pump case	B 8
GASKET, valve seat	B10
GAGE, level	C 2
GEAR, balance wt	B 4
GEAR, drive	B 3
*	B 6
*	D 8
GEAR, mPeller shaft	B 6
GEAR, kick	C 3
GEAR, kick idle	C 3
GEAR, meter	D 8
GEAR, Primary drive (22T)	C 4
GEAR, Pump drive	B 8
GEAR, 1st wheel (35T)	C 5
GEAR, 2nd Pinion (14T)	C 5
GEAR, 2nd wheel (31T)	C 5
GEAR, 3rd/4th Pinion (21T)	C 5
GEAR, 3rd wheel (28T)	C 5
GEAR, 4th wheel (25T)	C 5
GEAR, 5th Pinion (23T)	C 5
GEAR, 5th wheel	C 5
GEAR, 6th Pinion	C 5
GEAR, 6th wheel	C 5
GRAPHIC SET	D 6
*	D 6
*	D 6
GRIP (L.H)	D12
GRIP (R.H)	D12
GROMMET	B 7
*	B 7
*	B 7
*	B14
*	B15
*	C 9
*	C11
*	C11
*	C11
*	C12
*	E 2
*	E 2

PARTS NAME INDEX

DESCRIPTION	GRID NO.
GUARD, chain	C13
GUIDE, cable	B12
*	D 2
*	D 2
*	D 4
*	D 5
GUIDE, chain	C13
GUIDE, rotor	D12
HANDLE, seat	D 7
HANDLEBAR	D12
HEAD, cylinder 1	B 2
HEADLIGHT UNIT ASSY	E 5
HELMET HANGER ASSY	C 9
HOLDER	B12
*	B15
*	D12
HOLDER 1	B 2
HOLDER, cable	D 2
HOLDER, cable 1	D 2
HOLDER, cable 2	D 2
*	D 4
HOLDER, handle upper	D 2
HOLDER, lever 1	E 9
HOLDER, lever 2	E 9
HOLDER, oil P.Pe	E 9
HOLDER, sPcket	C 5
HOOK, seat	D 7
HORN	E 8
HOSE	B 8
*	B15
*	C12
*	D 6
*	E 7
HUB, front	D 8
HUB, rear	D10
IGNITION COIL ASSY	E 7
IMPELLER SHAFT ASSY	B 6
INNER TUBE COMP.1	D 3
*	D 4
JET, main (#075)	B12
JET, main (#080)	B12
JET, main (#085)	B12
JET, Pilot (#20.0)	B12
JOINT	B 7
JOINT 1	B 7
JOINT, air cleaner 1	B11
JOINT, carburetor	B10

PARTS NAME INDEX

DESCRIPTION	GRID NO.
JOINT, chain	D11
KEY, straight	B 3
*	B 4
*	C 7
KEY, woodruff	B 3
KICK AXLE ASSY	C 3
KICK CRANK ASSY	C 3
LEAD WIRE ASSY	B 5
LENS ASSY	E 5
LENS, flasher	E 3
*	E 3
LENS, taillight	E 6
LEVER 1	E 9
LEVER 2	E 9
LEVER, camshaft	D10
LEVER, camshaft 1	D 8
LEVER, seat	D 7
LINK, side stand	D14
MAIN SWITCH ASSY	E 7
METAL, slide 1	D 3
*	D 4
METAL, slide 2	D 3
*	D 4
METAL, worm shaft outer	B 8
NEEDLE	B12
NEEDLE VALVE ASSY	B12
NET, filter 2	D 6
NEUTRAL SWITCH ASSY	E 7
NOZZLE	B 8
NOZZLE, main	B12
NUT	B 2
*	B 4
*	B 5
*	B 3
*	B14
*	C 3
*	C 4
*	C 4
*	C 4
*	C13
*	C14
*	D 2
*	D10
*	D12
*	D12
*	D14
*	E 4

PARTS NAME INDEX

DESCRIPTION	GRID NO.
NUT	E 6
NUT, adjusting	E 5
NUT, cable adjusting	B12
NUT, castle	D 9
*	D11
NUT, crown	B 2
NUT, flange	E 3
*	E 3
*	E 4
NUT, self-locking	C 9
*	C13
*	D14
NUT, spring	D 7
NUT, u	C 9
*	C10
*	C15
*	D 8
*	D10
*	E 6
*	E 9
*	E 9
NUT, wing	D14
O-RING	B 7
*	B 8
*	B12
*	B12
*	B12
*	B13
*	B13
*	C 2
*	D 3
*	D 4
*	D 9
OIL LEVEL GAUGE ASSY	E 7
OIL PUMP ASSY	B 8
OIL SEAL	B 3
*	B 3
*	B 6
*	B 8
*	C 3
*	C 4
*	C 5
*	C 8
*	C13
*	C13
*	D 3
*	D 4
*	D 8
*	D 8

PARTS NAME INDEX

DESCRIPTION	GRID NO.
OIL SEAL	D 8
*	D10
PEDAL, brake	D14
*	D14
PIN	D 7
*	D12
*	D14
PIN, clevis	C14
*	C15
*	D14
*	D14
PIN, cutter	C14
*	C15
*	D 9
*	D11
*	D14
*	D14
*	D15
PIN, crank 1	B 3
PIN, dowel	B 2
*	B 6
*	B 6
*	B 8
*	B15
*	C 2
*	C 4
PIN, float	B12
PIN, piston	B 3
PIN, straight	C 7
PIPE	B12
*	B13
PIPE 1	B 7
PIPE 2	B 7
PIPE, breather	C12
PIPE, manifold	B10
*	B10
PIPE, oil tank breather	C12
PIPE, oil 1	B 8
PIPE, over flow	C12
PISTON (STD)	B 3
PISTON (1ST O/S 0.25MM)	B 3
PISTON (2ND O/S 0.50MM)	B 3
PISTON (3RD O/S 0.75MM)	B 3
PISTON (4TH O/S 1.00MM)	B 3
PISTON RING SET (STD)	B 3
PISTON RING SET (1ST O/S)	B 3
PISTON RING SET (2ND O/S)	B 3
PISTON RING SET (3RD O/S)	B 3
PISTON RING SET (4TH O/S)	B 3

PARTS NAME INDEX

DESCRIPTION	GRID NO.
PISTON RING, front fork	D 3
*	D 4
PISTON, front fork	D 3
*	D 4
PLATE	B11
*	C11
*	C11
PLATE, adjusting	B 8
PLATE, battery fitting	E 7
PLATE, brake shoe	D 8
*	D10
PLATE, clutch 1	C 4
PLATE, cover	C 5
PLATE, element fitting	B10
PLATE, friction	C 4
PLATE, indicator	D 8
*	D10
PLATE, Pressure 1	C 4
PLATE, Push 1	C 4
PLATE, side 1	C 7
PLATE, thrust 1	C 4
*	C 4
PLUG	B15
*	B15
*	D 8
PLUG CAP ASSY	E 7
PLUG, drain	D 3
*	D 4
PLUG, oil	C 2
PLUG, screw	B12
PLUG, spark	B 2
PLUG, straight screw	B15
PLUNGER, starter	B12
POINT, neutral	C 7
PRIMARY DRIVEN GEAR COMP.	C 4
PROTECTOR, silencer	B14
PROTECTOR, chain	C14
PROTECTOR, engine	C 9
PROTECTOR, handlebar	D13
PROTECTOR, muffler 1	B14
PULLER, chain 1	D10
PULLER, chain 2	D10
PUSH LEVER ASSY	C 4
RACE, ball 1	D 2
*	D 2
RACE, ball 2	D 2
*	D 2
RADIATOR ASSY	B 7

PARTS NAME INDEX

DESCRIPTION	GRID NO.
REAR ARM COMP.	C13
REAR FLASHER LIGHT ASSY 1	E 3
REAR FOOTREST ASSY 1	C13
RECTIFIER ASSY	E 8
REED VALVE ASSY	D 0
REED, valve	B10
REFLECTOR, rear 1	E 6
RIM (1.60-21)	D 8
RIM (1.85-18)	D10
RIM, headlight	E 5
RING, leaf	D12
RING, stop	D 9
RING, stopper	D 3
*	D 4
RIVET, blind	C10
ROD, brake	D14
ROD, connecting	B 3
ROD, Push 1	C 4
ROD, Push 2	C 4
ROTOR	D12
ROTOR ASSY	B 5
SCREW	D 6
SCREW, air adjusting	B13
SCREW, blind	B 7
*	B 8
*	B14
*	B14
SCREW, binding	B 7
SCREW, flat head	C 7
*	C 9
SCREW, lever fitting	D 6
SCREW, oval fillister	C11
*	C11
SCREW, Pan head	B 5
*	B 5
*	B 5
*	B 6
*	B 6
*	B 8
*	B10
*	B12
*	B15
*	B15
*	B15
*	B15
*	C 2
*	C 2

PARTS NAME INDEX

DESCRIPTION	GRID NO.
SCREW, Pan head	C 2
*	C 2
*	C 6
*	C13
*	D 4
*	E 3
*	E 3
*	E 7
*	E 7
*	E 8
*	E 8
*	E 9
*	C 9
*	E 9
SCREW, Pan head with washer	B10
*	B12
SCREW, Panhead tapping	B10
SCREW, rim adjusting	E 5
SCREW, tapping	D12
*	E 3
*	E 3
*	E 6
SCREW, throttle	B12
SCREW, with washer	E 5
SEAL	B10
*	B10
SEAL, camshaft	D10
SEAL, lock	D 6
SEAL, dust	D 3
*	D 4
SEAL, Guard	C13
*	C13
SEAL, steering	D 2
SEAT, spring	B13
*	D 3
*	D 4
SEAT, spring upper	D 3
*	D 4
SEGMENT	C 7
SHAFT	B 6
*	C 9
SHAFT, Pivot	C13
SHAFT, worm	B 8
SHIFT CAM ASSY	C 7
SHIFT PEDAL ASSY	C 8
SHIFT SHAFT ASSY	C 8
SHIM	C13
SHIM (0.3T)	B 8

PARTS NAME INDEX

DESCRIPTION	GRID NO.
SHIM (0.5T)	B 8
SHIM (1.0T)	B 8
SHIM 1 (1.0T)	C 5
SHOCK ABSORBER ASSY, rear	C15
SILENCER, exha	B14
SLIDER, throttle	D12
SOCKET, cord assy	E 4
SOCKET, meter	E 4
SOCKET, Pilot light	E 5
SPACER	C 3
*	D 8
SPACER, bead	D10
SPACER, bearing	D10
SPACER, oil lock	D 3
*	D 4
SPANNER, sPecial	D 9
SPEEDOMETER ASSY	E 4
SPEEDOMETER CABLE ASSY	E 4
SPOKE SET, front	D 8
SPOKE SET, rear	D10
SPRING	D 3
*	D 4
SPRING, air adjusting	B13
SPRING, brake Pedal	D14
SPRING, check ball	B 8
SPRING, compression	C 3
*	C 4
*	D12
*	D14
SPRING, front fork	D 3
*	D 4
SPRING, rebound	D 3
*	D 4
SPRING, reflector	E 5
SPRING, screw	E 5
SPRING, tension	D 8
*	D10
*	D14
*	D14
SPRING, throttle stop	B12
SPRING, throttle valve	B13
SPRING, torsion	C 3
*	C 4
*	C 7
*	C 8
*	C13
*	D14
*	D15

PARTS NAME INDEX

DESCRIPTION	GRID NO.
SPROCKET, drive (15T)	C 5
SPROCKET, driven (49T)	D10
STAND, side	D14
STAY 1	F
STAY, chain case	C14
STAY, flasher	E 3
*	E 3
STAY, flasher 1	E 3
STAY, flasher 2	E 3
STAY, muffler 1	B14
STAY, regulator	B 7
STEERING LOCK ASSY	D 2
STOP SWITCH ASSY	C 7
STOPPER LEVER ASSY	C 7
STOPPER, main stand	D 7
STOPPER, reed valve	B10
SWITCH, handle 1	E 9
SWITCH, handle 4	E 9
TAILLIGHT BASE ASSY	E 6
TAILLIGHT UNIT ASSY	E 6
TANK, oil	C12
TENSIONER	C 9
*	C13
THERMO UNIT	E 8
TIRE (2.75-21)	D 8
TIRE (4.10-18)	D10
TOOL KIT	C 9
TOP, mixing chamber	B13
TUBE (2.75-21)	D 8
TUBE (4.10-18)	D10
TUBE, throttle Guide	D12
UNDER BRACKET COMP.	D 4
VALVE, throttle 1	B12
VOLTAGE REGULATOR ASSY	E 8
WASHER	B 3
*	C 5
*	C10
*	D10
*	E 8
WASHER, conical sPring	C 4
WASHER, lock	B 4
*	C 4
WASHER, needle valve	B12
WASHER, Plain	C 4
*	C 9
*	D 7
*	D14
WASHER, Plate	B 2
*	B 5

PARTS NAME INDEX

DESCRIPTION	GRID NO.
WASHER, ata	B 5
*	B 5
*	B 6
*	B 6
*	B 7
*	B 8
*	B10
*	B14
*	B14
*	B15
*	B15
*	C 3
*	C 3
*	C 3
*	C 4
*	C 5
*	C 5
*	C 7
*	C 9
*	C10
*	C10
*	C11
*	C11
*	C14
*	C15
*	D 6
*	D 8
*	D 8
*	D11
*	D14
*	D14
*	E 4
*	E 6
*	E 7
*	E 8
*	E 9
*	E 9
WASHER, sPecial	D 3
*	D 3
*	D 6
*	E 5
WASHER, sPring	B 5
*	B 5

PARTS NAME INDEX

DESCRIPTION	QTY
WASHER SPRING	E 5
*	E 5
*	E 7
*	E 8
*	E 8
*	E 10
*	E 4
*	E 13
*	E 15
*	D 4
*	D 6
*	E 2
*	E 4
*	E 6
*	E 7
*	E 7
*	E 9
*	E 9
WATER TEMPERATURE ASS	E 4
WEIGH	B 4
WIRE HARNESS ASSY	E 7
WIRE Plus lead	E 7
WIRE Plus lead	E 7